


## M-BUS to BACnet/IP Server Gateway

USER MANUAL

Version 1.0.2

Publication date 2023-08-08



Copyright © 2023 Intesis

#### Disclaimer

The information in this document is for informational purposes only. Please inform HMS Networks of any inaccuracies or omissions found in this document. HMS Networks disclaims any responsibility or liability for any errors that may appear in this document.

HMS Networks reserves the right to modify its products in line with its policy of continuous product development. The information in this document shall therefore not be construed as a commitment on the part of HMS Networks and is subject to change without notice. HMS Networks makes no commitment to update or keep current the information in this document.

The data, examples and illustrations found in this document are included for illustrative purposes and are only intended to help improve understanding of the functionality and handling of the product. In view of the wide range of possible applications of the product, and because of the many variables and requirements associated with any particular implementation, HMS Networks cannot assume responsibility or liability for actual use based on the data, examples or illustrations included in this document nor for any damages incurred during installation of the product. Those responsible for the use of the product must acquire sufficient knowledge in order to ensure that the product is used correctly in their specific application and that the application meets all performance and safety requirements including any applicable laws, regulations, codes and standards. Further, HMS Networks will under no circumstances assume liability or responsibility for any problems that may arise as a result from the use of undocumented features or functional side effects found outside the documented scope of the product. The effects caused by any direct or indirect use of such aspects of the product are undefined and may include e.g. compatibility issues and stability issues.

# Table of Contents

<b>1. Description and Order Codes .....</b>	<b>1</b>
<b>2. Gateway Capacity .....</b>	<b>2</b>
<b>3. General Information .....</b>	<b>3</b>
3.1. Intended Use of the User Manual .....	3
3.2. General Safety Information .....	3
3.3. Admonition Messages and Symbols .....	3
<b>4. Overview .....</b>	<b>5</b>
4.1. Inside the Package .....	5
4.2. Gateway Main Features .....	5
4.3. Gateway General Functionality .....	6
<b>5. Hardware .....</b>	<b>7</b>
5.1. Mounting .....	7
5.2. Connection .....	8
5.2.1. Gateway Connectors .....	8
5.2.2. Common Connections .....	10
5.2.2.1. Connecting the Gateway to the Power Supply .....	10
5.2.2.3. Connection Procedure for M-Bus .....	10
5.2.2.4. Connection Procedure for BACnet/IP .....	10
5.3. Technical Specifications .....	11
5.4. Dimensions .....	12
<b>6. M-Bus System .....</b>	<b>13</b>
6.1. General Description .....	13
6.2. M-Bus Interface .....	13
6.3. M-Bus Signals .....	13
<b>7. BACnet System .....</b>	<b>14</b>
7.1. General Description .....	14
7.2. BACnet Server .....	15
7.2.1. Description .....	15
7.2.2. BACnet/IP .....	16
<b>8. Setup Process with the Configuration Tool .....</b>	<b>17</b>
8.1. Prerequisites .....	17
8.2. Intesis MAPS Configuration and Monitoring Tool .....	17
8.2.1. Introduction .....	17
8.2.2. Create a New Project from a Template .....	18
8.2.3. Main Menu Overview .....	19
8.2.4. Connection Tab .....	19
8.2.5. Configuration Tab .....	19
8.2.6. Signals Tab .....	20
8.2.7. Receive/Send Tab .....	20
8.2.8. Diagnostic Tab .....	21

## 1. Description and Order Codes

### INBACMEBxxx0100 Protocol Translator Gateway

M-Bus to BACnet/IP Server Gateway

ORDER CODE	LEGACY ORDER CODE
INBACMEB0200100	IBBACMEB0200100
INBACMEB0500100	IBBACMEB0500100



#### NOTICE

The order code may vary depending on the product seller and the buyer's location.

## 2. Gateway Capacity

Element	INBACMEB0200100	INBACMEB0500100	Notes
Type of BACnet devices	IP		Communication with BACnet/IP.
Number of BACnet objects	500	1250	Maximum number of points that can be defined in the virtual BACnet device inside the gateway.
Number of BACnet subscription (COV) requests	1000	2500	Maximum number of BACnet subscription (COV) requests accepted by the gateway.
Type of M-Bus devices	M-Bus EIA-485 slave devices		Those supporting the M-Bus EN-1434-3 Standard. Communication over EIA-485.
Number of M-Bus slave devices	20	50	Number of M-Bus slave devices supported by the gateway.
Number of M-Bus signals	500	1250	Number of M-Bus signals (readings in the meters) that can be read from the gateway.

## 3. General Information

### 3.1. Intended Use of the User Manual

This manual contains the main features of this Intesis gateway and the instructions for its appropriate installation, configuration, and operation.

The contents of this manual should be brought to the attention of any person who installs, configures, or operates this gateway or any associated equipment.

Keep this manual for future reference during the installation, configuration, and operation.

### 3.2. General Safety Information



#### IMPORTANT

Follow these instructions carefully. Improper work may seriously harm your health and damage the gateway and/or any other equipment connected to it.

Only technical personnel, following these instructions and the country legislation for installing electrical equipment, can install and manipulate this gateway.

Install this gateway indoors, in a restricted access location, avoiding exposure to direct solar radiation, water, high relative humidity, or dust.

All wires (for communication and power supply, if needed) must only be connected to networks with indoor wiring. All communication ports are considered for indoor use and must only be connected to SELV circuits.

Disconnect all systems from their power source before manipulating and connecting them to the gateway.

Use SELV-rated NEC class 2 or limited power source (LPS) power supply.

Supply always a correct voltage to power the gateway. See [Technical Specifications \(page 11\)](#).

Respect the expected polarity of power and communication cables when connecting them to the gateway.

### 3.3. Admonition Messages and Symbols



#### DANGER

Instructions that must be followed to avoid an imminently hazardous situation that, if not avoided, will result in death or severe injury.



#### WARNING

Instructions that must be followed to avoid a potentially hazardous situation that, if not avoided, could result in death or severe injury.



#### CAUTION

Instruction that must be followed to avoid a potentially hazardous situation that, if not avoided, could result in minor or moderate injury.



#### IMPORTANT

Instruction that must be followed to avoid a risk of reduced functionality and/or damage to the equipment or to avoid a network security risk.

**NOTE**

Additional information which may facilitate installation and/or operation.

**TIP**

Helpful advice and suggestions.

**NOTICE**

Remarkable Information.

## 4. Overview

This Intesis® gateway allows to integrate M-Bus devices into BACnet/IP systems easily.

The aim of this integration is to make M-Bus devices accessible from a BACnet control system or device to get the same behavior as if the M-Bus device was part of the BACnet installation.

For this, the Intesis gateway acts as a BACnet/IP client device in its BACnet interface, allowing it to read/write points from the BACnet Server device(s). From the M-Bus point of view, the gateway acts as an M-Bus level converter and Master device (EN-1434-3). The gateway performs the readings of the M-Bus slave device(s) by automatic continuous polling, or on demand (to reduce battery consumption).

The gateway configuration is carried out through the Intesis MAPS configuration tool.




Figure 1. Integration of M-Bus devices into BACnet/IP installations



### IMPORTANT

This document assumes that the user is familiar with BACnet and M-Bus technologies and their technical terms.

## 4.1. Inside the Package

Items included:

- Intesis INBACMEBxx0100 Protocol Translator Gateway
- Installation sheet

## 4.2. Gateway Main Features

- Embedded level converter. Direct connection to M-Bus devices with no extra hardware required.
- Scan function: detect M-Bus devices and their available registers automatically.
- Import/Export of M-Bus device templates.
- Baud rate configurable within the M-Bus allowed range (300 to 9600 bps. The devices are normally configured at 2400 bps).
- Specific parameters and timeouts are available to maximize compatibility with any possible peculiarity between different meter manufacturers.
- Availability of variables for communication errors, both at meter and general level, helping you to know if the communication with one or more meters has failed.
- Flexible configuration using the Intesis MAPS configuration tool.

### 4.3. Gateway General Functionality

This gateway acts as a server on its BACnet side and as a master on its M-Bus interface, thus allowing the integration of M-Bus devices into a BACnet system.

The gateway is continuously polling the devices (together or individually), storing in its memory the current status of every signal you want to track, and serving this data to the installation when requested. This continuous polling can be activated/deactivated through a BACnet signal. It is also possible to configure the gateway to make a single polling of the meters (refresh of readings) at start up.

Primary or secondary addressing is allowed for M-Bus devices. When a signal status changes, the gateway sends a write telegram to the installation, waits for the response, and performs the corresponding action.

This action can be: force a polling of a specific M-Bus device or force a polling of all M-Bus devices. This can also be forced from the BACnet side at any time by writing a 1 in the corresponding binary point specially enabled for this purpose.

Other M-Bus information accessible from BACnet, using specific points of the gateway, is:

- Bus activity: Indicates if meters are currently being polled or polling is on standby.
- M-Bus status of every meter: This is sent by the own meter with every poll and indicates the internal status, which is manufacturer specific in every case.

A lack of response from a signal activates a communication error, allowing you to know which signal from which M-Bus device is not correctly working. There is also a general communication error available that will be active whenever the communication with one or more M-Bus meters has failed.

## 5. Hardware

### 5.1. Mounting



#### IMPORTANT

Before mounting, please ensure that the chosen installation place preserves the gateway from direct solar radiation, water, high relative humidity, or dust.



#### NOTE

Mount the gateway on a wall or over a DIN rail. DIN rail mounting inside a grounded metallic cabinet is recommended.




#### IMPORTANT

Ensure the gateway has sufficient clearances for all connections when mounted. See [Dimensions \(page 12\)](#).

#### Wall mounting


1. Press the rear panel clips until you hear a *click*.
2. Use the clip holes to screw the gateway to the wall.
3. Make sure the gateway is firmly fixed.



#### DIN rail mounting

Keep the top side clip in its original position.

1. Insert the gateway in the upper edge of the DIN rail.
2. Fit the low side of the gateway in the DIN rail.
3. Push the bottom clip back to its original position, locking the gateway to the rail.
4. Make sure the gateway is firmly fixed.



## 5.2. Connection



### CAUTION

Disconnect all systems from the power source before manipulating and connecting them to the gateway.



### IMPORTANT

Keep communication cables away from power and ground wires.

### 5.2.1. Gateway Connectors




Figure 2. General view of all gateway connectors

1. **Power supply:** 24 VDC, Max.: 220 mA, 5.2 W

2. **Port A:** M-Bus port, for M-Bus bus connection

3. **Ethernet Port:** For BACnet/IP connection

Port A connectors	M-Bus wires
A1	+
A2	-



### NOTE

You can also use the **Ethernet Port** to connect the gateway to the PC for configuration purposes.



### NOTE

Mount the gateway in the desired installation site before wiring.

**IMPORTANT**

Use solid or stranded wires (twisted or with ferrule).

Wire cross-section/gauge for all wire connectors:

- One core: 0.2 to 2.5 mm<sup>2</sup> (24 to 11 AWG).
- Two cores: 0.2 to 1.5mm<sup>2</sup> (24 to 15 AWG).
- Three cores: Not permitted.

**NOTE**

To know more about each port's specifications, see [Technical Specifications \(page 11\)](#).

## 5.2.2. Common Connections

### 5.2.2.1. Connecting the Gateway to the Power Supply

The power supply connector is a green pluggable terminal block (3 poles) labeled as **24Vdc**.



#### IMPORTANT

- Use SELV-rated NEC class 2 or limited power source (LPS) power supply.
- Connect the gateway's ground terminal to the installation grounding.
- A wrong connection may cause earth loops that can damage the Intesis gateway and/or any other system equipment.

Apply the voltage within the admitted range and of enough power:

- 24 VDC, Max.: 220 mA, 5.2 W



#### IMPORTANT

- Respect the polarity labeled on the power connector for the positive and negative wires.

## 5.2.3. Connection Procedure for M-Bus

The gateway connects directly to the M-Bus system without requiring any external RS-232 or EIA-485 to M-Bus level converter.

Connect the M-Bus bus to connectors A1 (+) and A2 (-) of the gateway's Port A. Respect the polarity.

Remember that the gateway provides 36 VDC M-Bus voltage to the bus, acting also as an M-Bus level converter.

In case no response from the M-Bus device(s) to the frames sent by the gateway is received, check that they are operative and reachable from the network connection used by the gateway.

## 5.2.4. Connection Procedure for BACnet/IP



#### NOTE

Remember to check the [Common Connections \(page 10\)](#).

- Connect the BACnet/IP Ethernet cable to the gateway's **Ethernet Port**. The correct cable to use depends on where the gateway is connected:
  - **Connecting directly to a BACnet/IP device:** Use a crossover Ethernet UTP/FTP CAT5 or higher cable.
  - **Connecting to a hub or switch of the LAN of the building:** Use a straight Ethernet UTP/FTP CAT5 or higher cable.



#### IMPORTANT

When commissioning the gateway for the first time, DHCP will be enabled for 30 seconds. After that time, the default IP address 192.168.100.246 will be set.



#### NOTE

The default UDP port is 47808.



#### IMPORTANT


If communicating through the LAN of the building, contact the network administrator and make sure traffic on the used port is allowed through all LAN paths.

## 5.3. Technical Specifications

<b>Case</b>	Plastic, type PC (UL 94 V-0). Color: Light Grey. RAL 7035 Net dimensions (dxwxh): 93 x 53 x 58 mm / 3.6 x 2.1 x 2.3" Recommended space for installation (dxwxh): 100 x 60 x 70 mm / 3.9 x 2.4 x 2.7"
<b>Mounting</b>	Wall DIN rail (recommended mounting) EN60715 TH35
<b>Terminal wiring For power supply and low-voltage signals</b>	Per terminal: solid wires or stranded wires (twisted or with ferrule) Wire cross-section/gauge: One core: 0.2 mm <sup>2</sup> .. 2.5 mm <sup>2</sup> (24 .. 11 AWG) Two cores: 0.2 mm <sup>2</sup> .. 1.5 mm <sup>2</sup> (24 .. 15 AWG) Three cores: Not permitted  For distances longer than 3.05 meters (10 feet), use Class 2 cables.
<b>Power</b>	1 x Green pluggable terminal block (3 poles) 24 VDC, Max.: 220 mA, 5.2 W Recommended: 24 VDC, 220 mA
<b>Ethernet</b>	1 x Ethernet 10/100 Mbps RJ45
<b>Port A</b>	1 x M-Bus port: pluggable terminal block (2 poles) M-Bus power consumption: 90 mA Voltage rating: 36 VDC
<b>Operational temperature</b>	Celsius: 0 .. 60°C / Fahrenheit: 32 .. 140°F
<b>Operational humidity</b>	5 to 95%, no condensation
<b>Protection</b>	IP20 (IEC60529)
<b>LED indicators</b>	2 x Onboard LED indicators Ethernet Link/Speed

## 5.4. Dimensions

- **Net dimensions (DxWxH)**  
Millimeters: 93 x 53 x 58 mm  
Inches: 3.6 x 2.1 x 2.3"
- **Clear space for installation (DxWxH)**  
Millimeters: 100 x 60 x 70 mm  
Inches: 3.9 x 2.4 x 2.7"



## 6. M-Bus System

### 6.1. General Description

The M-Bus ("Meter-Bus") is a European standard for remote reading of heat meters, and it is also usable for all other types of consumption meters, as well as for various sensors and actuators.

M-Bus standards are:

- EN 13757-2 (physical and link layer)
- EN 13757-3 (application layer)

Many manufacturers of energy meters, pulse counters, water meters, electricity meters, etc., add an M-Bus interface to their devices, enabling them to be interconnected and remotely monitored through a 2-wire bus based on the M-Bus standards. There are many manufacturers of these measurement devices incorporating the M-Bus interface, and also some other manufacturers of specific M-Bus communication devices such as bus repeaters, EIA-232/EIA-485 to M-Bus level converters, etc.

### 6.2. M-Bus Interface

The gateway connects directly to the M-Bus system. No external level converter is required.

Connection to the M-Bus is made via the EIA-485 connection. Notice that the gateway also powers the bus, so no extra hardware is required to connect to M-Bus compatible meters or devices.

### 6.3. M-Bus Signals

The gateway supports several meter magnitudes and units typically used on the energy, electric, water, and other meters. During the scan, the gateway imports each signal with the units and details provided by the meter. See the details of the units on the [Signals tab \(page 20\)](#) in Intesis MAPS.

The type of signals available from every meter may differ, depending on the manufacturer and model. Please refer to the device's technical documentation to determine the signals available for a given meter to integrate the desired ones.

Besides this, to simplify and speed up the identification of the signals offered by any device (and their type), a scanning function has been embedded in the firmware of the gateway to poll the meter and show details about the signals offered by the device and the corresponding signal code needed in the signals list of the gateway for every one of the signals to integrate, using the Intesis MAPS configuration tool.

## 7. BACnet System

### 7.1. General Description

BACnet is a solid standard with many detailed concepts, but for this manual purposes, we will focus on the two most fundamental concepts:

- BACnet client, which is the device that sends service requests to the server.
- BACnet server, which is the device that performs the requested service and reports the result back to the client.

BACnet server devices are represented in the form of *devices* holding *objects*. Usually, every physical device corresponds to a logical one. The objects can be of different types depending on the data and functionality they represent: Analog input, Analog output, Digital input, etc.



#### NOTE

- Output objects are meant to be written from the BACnet network to the device.
- Input objects are meant to offer status information on the BACnet device.
- Value objects are bidirectional.

Every object has different properties. The most meaningful one is the **Present\_Value** property, which indicates the real value of the object. Also, the gateway uses this property to read and write values. Every object of the same type in a device is identified with its associated **object instance**.



#### NOTE

Refer to the [Protocol Implementation Conformance Statement \(PICS\) document](#) for more information.



#### NOTE

This model supports BACnet descriptions; this is configurable through the Intesis MAPS configuration tool.

## 7.2. BACnet Server

### 7.2.1. Description



#### NOTICE

When the Intesis gateway acts as a server device, it is classified under the device profile of a BACnet Advanced Application Controller (B-AAC). For further details, check out the product website for the BACnet client PIC statements.

Using the Intesis MAPS configuration tool, you can configure the object type associated with the signal on the other protocol.

To facilitate the translation towards BACnet, the following object type options are available:

Object Type	ID
Analog-Input	0
Analog-Output	1
Analog-Value	2
Binary-Input	3
Binary-Output	4
Binary-Value	5
Calendar	6
Device	8
Multistate-Input	13
Multistate-Output	14
Multistate-Value	19
Notification-Class	15
Schedule	17
Trend-Log	20
Trend-Log-Multiple	27

Every signal of the Intesis gateway can have several objects. These objects and their properties can be configured with the Intesis MAPS configuration tool.

Depending on the field device protocol, you can define the signals using one of the following options:

- Configuring them manually for each or multiple signals at the time.
- Importing a file with the signals of the field devices.
- Scanning the network of the devices if this is supported.



#### NOTICE

The configuration tool provides default templates that make this signals assignment process easier. Also, you only have to click the **Check table** button on the bottom right corner of the window to know if everything is correct or if there's some mistake. The project is also automatically checked before you transfer it to the gateway.

All objects definition, BIBBs, and details about the implementation can be found on the BACnet server PICS on the product website.

### 7.2.2. BACnet/IP

The UDP communication port is the main setup parameter for BACnet/IP, besides basic IP settings (IP, netmask, default gateway). The Intesis gateway uses the 47808 (0xBAC0) port by default, which you can change through the configuration tool.

When using BACnet/IP, the gateway can also act as a foreign device to communicate with devices in another network domain. Alternatively, you can set it as a BBMD (Bacnet/IP Broadcast Management Device). This functionality facilitates the communication of devices placed in other networks with the devices in the gateway network.

## 8. Setup Process with the Configuration Tool

### 8.1. Prerequisites

For this integration, you need:

- The items delivered by HMS Networks:
  - The Intesis INBACMEBxxx0100 Protocol Translator Gateway.
  - [Link to download the configuration tool](#).
  - Product documentation.
- The respective M-Bus devices connected to the Port A of the gateway.
- A computer to run the Intesis MAPS configuration tool.  
Requirements:
  - Windows® 7 or higher.
  - Hard disk free space: 1 GB.
  - RAM: 4GB.
- An Ethernet cable.

### 8.2. Intesis MAPS Configuration and Monitoring Tool

#### 8.2.1. Introduction

Intesis MAPS is a software tool for the configuration and monitoring of the Intesis gateways. It has been designed and developed in-house, ensuring an up-to-date tool to get all the potential of our gateways. It is compatible with Windows® 7 and higher.

The installation procedure and the main functions are explained in the [Intesis MAPS user manual](#). Please also check the Intesis MAPS user manual for specific information about the different parameters and how to configure them.

## 8.2.2. Create a New Project from a Template

1. Open Intesis MAPS.
2. Click **Create New Project** in the **Getting started** menu on the left.

You can create a project from scratch using a template. To find the appropriate template, filter the search by:

- Clicking on the protocol logos.
- Typing the order code in the **Order Code** field.



### NOTE

The order code is printed on the silver label placed on the gateway's right side.

- Looking for it on the list.

**New Project**

Select BMS Protocol

Select Template

**Order Code:**

Project Name	BMS Protocol	Device Protocol	Description	Gateway Order Code
IN-KNX-BAC	KNX	BACnet Client	Intesis BACnet Client to KNX Gateway	IN701KNXXXXXX0000 INKNXBACXXXXV000 INKNXBACXXXXV000
IN-KNX-DALI-64	KNX	DALI	Intesis DALI to KNX Gateway	INKNXDALB64V000 INKNXDALB64V000
IN-KNX-FJ	KNX	Fujitsu VRF	Intesis Fujitsu AC to KNX Gateway	INKNXFGLXXXXV000 INKNXFGLXXXXV000
IN-KNX-HI	KNX	Hitachi	Intesis Hitachi AC to KNX Gateway	IN770A1RXXXX0000 INKNKHITXXXXV000 INKNKHITXXXXV000
IN-KNX-HS	KNX	Hisense	Intesis Hisense AC to KNX Gateway	IN770A1RXXXX0000 INKNKHISXXXXV000 INKNKHISXXXXV000
IN-KNX-LG	KNX	LG	Intesis LG AC to KNX Gateway	IN770A1RXXXX0000 INKNXLGXXXXV000
IN-KNX-MBM	KNX	Modbus Master	Intesis Modbus Master to KNX Gateway	IN701KNXXXXXX0000 INKNXMBXXXXV000 INKNXMBXXXXV000
IN-KNX-MBUS	KNX	M-Bus	Intesis M-Bus to KNX Gateway	IN770A1RXXXX0000 INKNXMEXXXXV000 INKNXMEXXXXV000
IN-KNX-MD	KNX	Midea	Intesis Midea to KNX Gateway	IN770A1RXXXX0000
IN-KNX-ME	KNX	Mitsubishi Electric	Intesis Mitsubishi Electric AC to KNX Gate...	IN770A1RXXXX0000 INKNKHITXXXXV000 INKNKHITXXXXV000
IN-KNX-MH	KNX	Mitsubishi Heavy Industries	Intesis Mitsubishi Heavy Industries to KNX...	IN770A1RXXXX0000
IN-KNX-PA	KNX	Panasonic	Intesis Panasonic to KNX Gateway	IN770A1RXXXX0000 INKNXPANXXXXV000 INKNXPANXXXXV000
IN-KNX-SM	KNX	Samsung NASA	Intesis Samsung NASA AC to KNX Gateway	IN770A1RXXXX0000 INKNKSAWXXXXV000 INKNKSAWXXXXV000





Device model **700 Series Family**

Available Licenses

100 points  
250 points  
600 points  
1200 points  
3000 points

Order Codes

IN701KNX100000  
IN701KNX250000  
IN701KNX600000  
IN701KNX1K20000  
IN701KNX3K00000

Figure 3. The three possibilities for the template selection

3. Select the desired template.
4. Click **Next** or **double-click the template** on the list.



### NOTE

Templates are just examples of integration. Depending on the type of integration, you may have to modify some parameters.

### 8.2.3. Main Menu Overview



Figure 4. Intesis MAPS main menu

The following sections provide an overview of the five tabs that compose the Intesis MAPS main menu. Through these options, you will configure both the gateway and your project, and monitor that everything works fine using the **Diagnostic** tab.

### 8.2.4. Connection Tab

Click the **Connection** button in the menu bar to configure the gateway connection parameters.




Figure 5. Connection tab window

### 8.2.5. Configuration Tab

Select the **Configuration** tab to configure the connection parameters. This window contains three subsets of information: General (gateway general parameters), BACnet server (BACnet interface configuration), and M-Bus (M-Bus interface parameters).




Figure 6. Configuration tab window

## 8.2.6. Signals Tab

All available objects, object instances, their corresponding BACnet object, and other main parameters are listed in the **Signals** tab. More information on each parameter and how to configure it can be found in the Intesis MAPS user manual.

Figure 7. Signals tab for the BACnet server application


## 8.2.7. Receive/Send Tab

### Send:

Once you have finished setting the parameters, you have to send the configuration to the gateway.

Follow these steps:

1. Click the **Send** button.
  - a. If the gateway is still factory-set, you will be prompted to save the project on your PC. Once saved, the configuration is automatically sent to the gateway.
  - b. If you have already saved the project, the configuration is automatically sent to the gateway.
2. Connect again with the gateway after sending the file.



### NOTICE

The gateway will reboot automatically once the new configuration is loaded. This process may take a few seconds.

### Receive:

Use this function to get the configuration of a gateway, for example, when you need to change some parameters of a gateway already mounted in an installation.

Once the configuration is completed and sent, the gateway is already operative. Even so, you should check that everything is working correctly by entering the Diagnostic tab.

## 8.2.8. Diagnostic Tab



### IMPORTANT

Connection with the gateway is required to use the diagnostic tools.





Figure 8. Diagnostic tab window. Find the ToolBox between the upper tabs bar and the Console view. Below it, from left to right: Console viewer, Protocol viewers (one above the other), and the Signals viewer

This section has two main parts:

**ToolBox:**



Use the tools section to:

- Check the current hardware status of the gateway.
- Save communication logs to a ZIP file for diagnostic purposes.
- Get information on the gateway.
- Reset the gateway.

**Viewers:** Intesis MAPS provides several viewers:

- A generic console viewer for general information about communications and the gateway status.
- A viewer for both protocols to check their current status.
- A signals viewer to simulate the BMS behavior or check the system's current values.