



# User guide

## Energy measurement

MULTICAL® 603 functions as follows:

**The flow sensor** registers the volume of water that circulates through the system in cubic metres [m<sup>3</sup>].

**The temperature sensors** placed in inlet and outlet register the cooling, i.e. the difference between inlet and outlet temperatures.

**MULTICAL® 603** calculates the energy consumption on the basis of the volume of water and the temperature difference.

## Readings in the display

When one of the arrow keys (◀ or ▶) is activated, a new primary reading is displayed. The primary key (●) is used for retrieving historical readings and average values and for returning to primary readings.

Four minutes after the latest activation of any front key, the display automatically changes to energy consumption.

## Displays

