

	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 1 of 21

ELAUSYS

INV-KNX-HU

KNX Gateway for Huawei SUN2000 inverters

User Manual



 Electronic & Automation Systems	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 2 of 21

TABLE OF CONTENT

1. INTRODUCTION	3
2. OVERVIEW	4
2.1.....USAGE & LIMITATION.....	4
2.2.....CONNECTION DIAGRAM.....	5
2.3.....FRONT PANEL	6
2.4.....SOFTWARE.....	6
3. PARAMETERS	7
3.1.....GENERAL SETTINGS.....	7
4. COMMUNICATION OBJECTS	9
4.1.....GENERAL.....	9
4.2.....INVERTERS OBJECTS.....	9
4.3.....GROUP OBJECT LIST	12
5. CONFIGURATION	15
5.1.....NETWORK CONFIGURATION.....	15
5.2.....KNX PHYSICAL DEVICE.....	16
5.3.....ETS PARAMETERS	16
5.4.....ETS GROUP OBJECTS	17
5.5.....INVERTER CONFIGURATION.....	18
6. FIRMWARE VERSION	21
7. DATASHEET	21

	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 3 of 21

1. INTRODUCTION

The KNX gateway for Huawei SUN2000 inverters provides a simple solution to transfer all relevant data from Huawei inverters to KNX.

It allows integrators to take advantage of a fully integrated solar panel inverter, the data can be used to optimize energy consumption, monitoring, trending or to trigger specific action in the KNX installation.

Main features:

- KNX Interface for Huawei SUN2000 inverters serie
- Monitoring of Energy, Power, current, voltage, frequency, temperature, ...
- Connected to the inverter over Ethernet
- Galvanic insulation from the KNX bus
- Configurable refresh rate of inverter data
- DIN rail mounted
- Auxiliary power supply 12-30VDC



KNX GATEWAY FOR HUAWEI INVERTERS

	User Manual		Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters		Revision : 1.02
			Page : 4 of 21


2. OVERVIEW

2.1 USAGE & LIMITATION

This gateway is intended to be used with a HUAWEI inverter compatible with the SUN2000 modbus interface definition. Please refer to the inverter provider to check if your model is compatible with modbus TCP or contact us.

SUN2000 Series:


The SUN2000 series inverters are connected by ethernet using a SmartDongle. For SUN2000 series equipped with a SmartDongle, the firmware version of the dongle should be $\geq$ SPC120.



	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 5 of 21

SUN2000L Series:

The SUN2000L inverters are connected to the WIFI network on the same router as the KNX gateway.



2.2 CONNECTION DIAGRAM


The KNX bus is connected on the top side of the gateway.

An external power supply 12-30VDC is required and connected on the bottom side of the module, beside the RJ45 connector for the ethernet cable.



	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 6 of 21

2.3 FRONT PANEL



The front panel is equipped with two green status LED:

Network: Physical connection to the ethernet network is established.
Connected: Communication with the inverter is established.

Button "P" : KNX Programming mode button
Red LED : KNX Programming status LED

2.4 SOFTWARE

The KNX Interface is configured using the ETS tool, the free ETS Demo version can be [downloaded](#) from the website of KNX Association. The free version allows to configure up to 5 KNX modules in a project, the KNX gateway is only one module, all devices can be configured using this version.

	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 7 of 21

3. PARAMETERS

The KNX interface parameters are defined in the “parameters” tab of the device, in the ETS project.

3.1 GENERAL SETTINGS

The following parameters are defined in the General section of the device parameters:

PARAMETER	VALUES	DESCRIPTION
AC Network	▪ Single phase (default) ▪ Tri-Phase	Type of AC network
Number of PV Circuits	▪ 1 ... 4	Number of solar panel circuits to monitor
Inverter model	▪ 0...255	0 = HUAWEI SUN2000L 4 = HUAWEI SUN2000
Refresh rate (min)	▪ 0...255	Cyclic rate of data polling from the inverter.
Battery 1	▪ Not Used / Used	Display group objects to monitor the status of battery 1
Battery 2	▪ Not Used / Used	Display group objects to monitor the status of battery 2

	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 8 of 21

Powermeter	▪ Not Used / Used	Display group objects to monitor the powermeter value
Device Options	Text string	Device options are not available on this device.

 Electronic & Automation Systems	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 9 of 21

4. COMMUNICATION OBJECTS

4.1 GENERAL

General communication objects of the device.

GO	NAME	DESCRIPTION
1	Module status	Sends 0 when the module is operating normally, sends an error code when applicable.

4.2 INVERTERS OBJECTS

GO	NAME	DESCRIPTION
3	AC Current	AC Total Current value
4	AC Current A	AC Current phase A
5	AC Current B	AC Current phase B
6	AC Current C	AC Current phase C
7	AC Voltage	AC Total Voltage
8	AC Voltage AB	AC Voltage phase AB
9	AC Voltage BC	AC Voltage phase BC
10	AC Voltage CA	AC Voltage phase CA
11	AC Voltage AN	AC Voltage phase AN
12	AC Voltage BN	AC Voltage phase BN
13	AC Voltage CN	AC Voltage phase CN
14	DC Current	DC Total Current value (NOT USED)
15	DC Voltage	DC Total Voltage (NOT USED)
16	PV1 Voltage	PV1 Voltage
17	PV1 Current	PV1 Current
18	PV2 Voltage	PV2 Voltage

19	PV2 Current	PV2 Current
20	PV3 Voltage	PV3 Voltage
21	PV3 Current	PV3 Current
22	PV4 Voltage	PV4 Voltage
23	PV4 Current	PV4 Current
24	AC Power	AC Power
25	DC Power	DC Power
26	AC Frequency	AC Frequency
27	AC VA	AC Apparent power (NOT USED)
28	AC VAR	AC Reactive power
29	AC PF	Power factor
30	AC Energy	Total AC Energy
31	Efficiency	Inverter efficiency
32	Insulation	Insulation resistance
33	Temperature	Cabinet temperature
40	Daily Energy Yield	
41	Battery 1 Running Status	0: offline 2: standby 3: running 4: fault 5: sleep mode
42	Battery 1 power	> 0: charging < 0: discharging
43	Battery 1 SOC	Battery's state of capacity
44	Battery 1 current day charge	
45	Battery 1 current day discharge	
46	Battery 1 total charge	
47	Battery 1 total discharge	
48	Battery 2 Running Status	0: offline 2: standby 3: running 4: fault 5: sleep mode
49	Battery 2 power	> 0: charging < 0: discharging

 Electronic & Automation Systems	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 11 of 21

50	Battery 2 SOC	Battery's state of capacity
51	Battery 2 current day charge	
52	Battery 2 current day discharge	
53	Battery 2 total charge	
54	Battery 2 total discharge	
55	Powermeter	> 0: charging < 0: discharging

	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 12 of 21

4.3 GROUP OBJECT LIST

GO	Name	Function	Size	Flags	Type ID	Type Name	Description
1	Module status	Status code	1 byte	C R - T -	20.011	DPT_ErrorClass_System	Device status
3	AC Current	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	AC Total Current value
4	AC Current A	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	AC Current phase A
5	AC Current B	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	AC Current phase B
6	AC Current C	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	AC Current phase C
7	AC Voltage	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Total Voltage
8	AC Voltage AB	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Voltage Phase AB value
9	AC Voltage BC	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Voltage Phase BC value
10	AC Voltage CA	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Voltage Phase CA value
11	AC Voltage AN	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Voltage Phase AN value
12	AC Voltage BN	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Voltage Phase BN value
13	AC Voltage CN	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	AC Voltage Phase CN value
14	DC Current	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	DC Total Current value
15	DC Voltage	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	DC Total Voltage
16	PV1 Voltage	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	PV1 Voltage
17	PV1 Current	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	PV1 Current
18	PV2 Voltage	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	PV2 Voltage
19	PV2 Current	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	PV2 Current
20	PV3 Voltage	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	PV3 Voltage

	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 13 of 21

21	PV3 Current	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	PV3 Current
22	PV4 Voltage	Actual value	4 bytes	C R - T -	14.027	Electric potential (V)	PV4 Voltage
23	PV4 Current	Actual value	4 bytes	C R - T -	14.019	Electric current (A)	PV4 Current
24	AC Power	Actual value	4 bytes	C R - T -	14.056	Power (W)	AC Power
25	DC Power	Actual value	4 bytes	C R - T -	14.056	Power (W)	DC Power
26	AC Frequency	Actual value	4 bytes	C R - T -	14.033	Frequency (Hz)	AC Frequency
27	AC VA	Actual value	4 bytes	C R - T -	14.056	Power (W)	AC Apparent power
28	AC VAR	Actual value	4 bytes	C R - T -	14.056	Power (W)	AC Reactive power
29	AC PF	Actual value	4 bytes	C R - T -	14.057	Power factor (cos phi)	Power factor
30	AC Energy	Actual value	4 bytes	C R - T -	13.013	Active energy (kWh)	Total AC Energy
31	Efficiency	Actual value	2 bytes	C R - T -	8.010	Percentage (%)	Inverter efficiency
32	Insulation	Actual value	4 bytes	C R - T -	14.056	Resistance (Ohm)	Insulation resistance
33	Temperature	Actual value	2 bytes	C R - T -	9.001	Temperature (°C)	Cabinet temperature
34	Status 1	Status code	2 bytes	C R - T -	-	-	Device specific satus code
35	Status 2	Status code	2 bytes	C R - T -	-	-	Device specific satus code
36	Status 3	Status code	2 bytes	C R - T -	-	-	Device specific satus code
37	Status 4	Status code	2 bytes	C R - T -	-	-	Device specific satus code
38	Status 5	Status code	2 bytes	C R - T -	-	-	Device specific satus code
39	Status 6	Status code	2 bytes	C R - T -	-	-	Device specific satus code
40	Daily Energy Yield	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
41	Battery 1 Running Status	Actual value	2 bytes	C R - T -	-	-	Status code
42	Battery 1 power	Actual value	4 bytes	C R - T -	14.056	Power (W)	
43	Battery 1 SOC	Actual value	1 byte	C R - T -	5.001	Percentage (%)	State of charge (%)

	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 14 of 21

44	Battery 1 current day charge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
45	Battery 1 current day discharge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
46	Battery 1 total charge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
47	Battery 1 total discharge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
48	Battery 2 Running Status	Actual value	2 bytes	C R - T -	-	-	Status code
49	Battery 2 power	Actual value	4 bytes	C R - T -	14.056	Power (W)	
50	Battery 2 SOC	Actual value	1 byte	C R - T -	5.001	Percentage (%)	State of charge (%)
51	Battery 2 current day charge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
52	Battery 2 current day discharge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
53	Battery 2 total charge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
54	Battery 2 total discharge	Actual value	4 bytes	C R - T -	13.013	Energy (kWh)	
55	Powermeter	Actual value	4 bytes	C R - T -	14.056	Power (W)	


	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 15 of 21

5. CONFIGURATION

5.1 NETWORK CONFIGURATION

By default, the IP address of the KNX gateway is set to **192.168.1.51**

Using a laptop connected to the gateway, open a web browser and navigate to the IP address of the gateway.



Set a fixed IP address of your choice for the KNX gateway and configure the modbus TCP settings as below:

SUN2000 series :

- Mode : Connect
- Server IP : IP address of the inverter
- Server Port : 502
- Uni Id : 1

SUN2000L series :


- Mode : Listen
- Server Port : 502
- Uni Id : 0

	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 16 of 21

5.2 KNX PHYSICAL DEVICE

ELAUSYS devices are configured using the ETS tool. You should first download and install the free version of ETS tool before you continue.

The INV-KNX Interface must be assigned a physical address on the KNX network. Assign a free address to the module, in our example we choose 1.1.2.



5.3 ETS PARAMETERS

Once a KNX physical address is set, open the parameter tab to configure the interface.

1.1.30 ELAUSYS INV-KNX > General

General	AC Network	
	Number of PV circuits	☐ Single-phase ☒ Tri-phase 2
	Inverter model	0
	Refresh rate (min)	1
	Battery 1	☐ Not used ☒ Used
	Battery 2	☐ Not used ☒ Used
	Powermeter	☐ Not used ☒ Used
	Device options :	

Select the type of AC network (single phase or tri-phase).

Select the number of solar panel circuits to monitor.

Set the **inverter model to 0 for SUN2000L or to 4 for SUN2000** Huawei inverters

Choose the refresh rate (min) for the complete set of data.

Select if batteries or powermeter are available on the inverter.

Device options should remain empty.

	User Manual		Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters		Revision : 1.02
			Page : 17 of 21

5.4 ETS GROUP OBJECTS

A group address (GA) must be assigned to each group object (GO) needed by the application. Open the Group Objects tab of the device and assign a GA to the objects as needed.


	Number	Name	Object Function	Description	Group Address	Length	C	R	W	T	U	Data Type	Priority
1	1	Module status	Status code	Status	0/0/1	1 byte	C	R	-	T	-	system err...	Low
2	2	Firmware version	Text string	FW	0/0/2	14 bytes	C	R	-	T	-	Character...	Low
3	3	AC Total Current	Actual value	Value	1/0/0	4 bytes	C	R	-	T	-	electric cur...	Low
7	7	AC Total voltage	Actual value	Value	1/0/1	4 bytes	C	R	-	T	-	electric po...	Low
14	14	DC Total Current	Actual value	Value	1/0/2	4 bytes	C	R	-	T	-	electric cur...	Low
15	15	DC Total voltage	Actual value	Value	1/0/3	4 bytes	C	R	-	T	-	electric po...	Low
16	16	PV1 Voltage	Actual value	Value	1/0/4	4 bytes	C	R	-	T	-	electric po...	Low
17	17	PV1 Current	Actual value	Value	1/0/5	4 bytes	C	R	-	T	-	electric cur...	Low
24	24	AC Power	Actual value	Value	1/0/6	4 bytes	C	R	-	T	-	power (W)	Low
25	25	DC Power	Actual value	Value	1/0/7	4 bytes	C	R	-	T	-	power (W)	Low
26	26	AC Frequency	Actual value	Value	1/0/8	4 bytes	C	R	-	T	-	frequency...	Low
27	27	AC Apparent power	Actual value	Value	1/0/9	4 bytes	C	R	-	T	-	power (W)	Low
28	28	AC Reactive power	Actual value	Value	1/0/10	4 bytes	C	R	-	T	-	power (W)	Low
29	29	AC power factor	Actual value	Value	1/0/11	4 bytes	C	R	-	T	-	power fact...	Low
30	30	AC Energy	Actual value	Value	1/0/12	4 bytes	C	R	-	T	-	active ener...	Low
31	31	Inverter efficiency	Actual value	Value	1/0/13	2 bytes	C	R	-	T	-	percentag...	Low
32	32	Inverter resistance	Actual value	Value	1/0/14	4 bytes	C	R	-	T	-		Low
33	33	Cabinet Temperature	Actual value	Value	1/0/15	2 bytes	C	R	-	T	-	temperatu...	Low
34	34	Manufacturer specific status code	Status code	Value	1/0/16	2 bytes	C	R	-	T	-		Low
35	35	Manufacturer specific status code	Status code	Value	1/0/17	2 bytes	C	R	-	T	-		Low
36	36	Manufacturer specific status code	Status code	Value	1/0/18	2 bytes	C	R	-	T	-		Low
37	37	Manufacturer specific status code	Status code	Value	1/0/19	2 bytes	C	R	-	T	-		Low
38	38	Manufacturer specific status code	Status code	Value	1/0/20	2 bytes	C	R	-	T	-		Low
39	39	Manufacturer specific status code	Status code	Value	1/0/21	2 bytes	C	R	-	T	-		Low

When GO and parameters are all configured, download the KNX Interface application to the device. The first download requires to press the programming button on the device to set the device in KNX programming mode then perform a full download.

5.5 INVERTER CONFIGURATION

SUN2000 Series :

From the Fusion Solar portal, verify that the SmartDongle software version is $\geq$ SPC120.



Overview Layout Reports Devices Alarms							
Device type: All Device name: SN: Search							
Set Parameters Replace Device Delete Export Basic Info Export Performance Data							
☐	Communication Status	Device Name	Plant Name	Device Type	Software Version	SN	Operation
☐	●	2101073804HVHA000147	Ger7 Luna	Inverter	V100R001C00SPC334	2101073804HVHAC	
☐	●	HV19A0104325	Ger7 Luna	Smart Dongle	V100R001C00SPC120	HV19A0104325	
☐	●	HV20B0015511	Ger7 Luna	Inverter	V100R001C00SPC134	HV20B0015511	

Total records: 3 1 / 10 / page

If the software version is not up to date, there are two ways to perform the firmware upgrade:

1. Local via APP
You can download the latest version from Huawei homepage.
<https://support.huawei.com/enterprise/en/digital-power/sdongle-pid-23826585/software>
2. Upgrade via Portal:
Plants > Upgrade Management > Add
Select Device type: Smart Dongle > SPC 120 and Device

SUN2000L Series :


Inverter configuration is only required for SUN2000L inverters.

Install the Huawei mobile application “FusionHome” on your smartphone.

If your inverter is not yet connected to the WIFI network, follow the instructions from the video below :


https://www.youtube.com/watch?v=EDbOp_GIXDE

	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 19 of 21



In the application, select your inverter and login using the installer code. Default code is **00000a**

	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 20 of 21




From the home page choose “Communication configuration”, set the management system connection parameters:

- Set at domain name: **IP address of the KNX gateway**
- Assure that the port is 502 and encrypted transmission is disabled.
- After you set the domain name and the port, press “Connect”
- Check that the connection with the KNX gateway is established on the front panel of the KNX gateway, the status LED “Connected” should be ON.

	User Manual	Doc.Ref : INV-KNX-HU-UM
	KNX Gateway for Huawei Inverters	Revision : 1.02
		Page : 21 of 21

6. FIRMWARE VERSION

This user manual and related ETS application is valid for firmware versions V1.1.4.0 and above.
The firmware version can be read from the gateway webpage using a web browser.
It is displayed on the top right of the page.



In case an updated firmware would be available, the device can be updated from the FW Update page, the binary file should be selected before pressing the Update button.

7. DATASHEET

TECHNICAL DATA	VALUE
Auxiliary power supply terminal	Screw terminal 12-30VDC / GND
Power consumption KNX bus typ.	< 16 mA @ 29VDC
Operating temperature	+5°C to + 45°C
Enclosure Dimensions (Space Units)	2 SU
Mounting	DIN RAIL
KNX terminal	Pluggable micro terminal, Red/Black, 4 pole PUSH WIRE for solid conductor wire 0.6-0.8 mm ²
KNX bus voltage	29 VDC