



Commissioning instruction  
**Smart Gateway**

**SG 150-0**

# Contents

<b>Quick overview –</b>	
<b>Commissioning</b>	3
<b>Safety remarks</b>	
Observe the safety instructions!	4
Servicing	4
Privacy by Default	4
Product registration	4
Automatic logout	4
<b>Overview</b>	
System overview	5
Commissioning sequence	6
Bus addresses in the In-Home bus	7
Functions applicable across individual lines	7
Connection of bus and IP address	7
Example – Single line system	8
Example – Multiple line system	8
System limits	8
<b>Preparation</b>	
Menu structure User interface	9
Information on programming	10
Programming with Bus programming software BPS 650-...	10
Manual programming, also called “Teach-In”	10
Remarks on the Finder function	10
Direct LAN connection	11
Indirect LAN connection with active DHCP server	11
Indirect LAN connection with inactive DHCP server	12
<b>Commissioning requirements</b>	
Step-by-step through the commissioning process	14
Register product	14
Downloading and installing the bus programming software	14
<b>Commissioning</b>	
Manual programming	15
Programming using the PC and bus programming software (BPS 650-...)	16
Performing a system update	16
Change user profile / password	17
Setting the date and time	17
Check/change the network settings	17
Setting video memory/door call	17
Video settings	17
Creating IP users	18
Deleting IP users	18
Creating IP groups	18
Storey call – Defining IP users/ IP group	18
Registering IP users	18
Programming in the In-Home bus	18
Import In-Home bus configuration	19
Siedle app	19
Commission the Siedle app	19
Telephony connection	
Siedle Axiom	19
Set up SIP client	20
Direct door call per DTMF	20
Link Siedle Axiom	20
Call number prefixes	20
<b>Mobile network connection</b>	
Sequence: Install the mobile network connection	21
Infographic: Connecting a Mobile Terminal to a Smart Gateway	21
Minimum requirements for stationary internet connection	22
Minimum requirements for mobile terminals	22
Commission the Siedle app	22
Infographic: Mobile phone network requirements	23
<b>Reset or check the settings</b>	
Resetting the system	24
Restarting the Gateway	24
IP address and password reset	24
DHCP server – Changes	24
<b>Optional commissioning steps</b>	
Reserving bus addresses	25
Licenses	25
User licences	25
Function licences	25
Logging	26
Backing up/ Restoring the system	26
<b>Index</b>	27

These commissioning instructions supplement/are supplemented by:

- Product Information
- Smart Gateway SG 150-0
- System Manual In-Home bus: Video

The relevant current edition is located in the download area on [www.siedle.com](http://www.siedle.com)

## Subject to printing errors.

We reserve modifications depending on technical improvements.

## Quick overview – Commissioning

Observe the safety instructions!	4
Checking, selecting and preparing the network connection	17
Fulfilling commissioning requirements	14
Register product	14
Downloading and installing the bus programming software	14
Programming the Gateway in the In-Home bus and exporting the configuration	10
Login on the Gateway	16
Performing a system update	16
Change user profile / password	17
Setting the date and time	17
Check/change the network settings	17
Setting video memory/door call	17
Import In-Home bus configuration	19
Creating IP users / Creating IP groups	18
Storey call – Defining IP users/IP group	18
Registering IP users	18
Set up the mobile network connection	21
Carry out a function check	24

## Safety remarks

### Observe the safety instructions!

Read and observe the safety instructions and content of the following documents before using the Gateway for the first time:

- Product information sheet
- Commissioning instructions
- System Manual In-Home bus: Video

Explain the content of the safety instructions and dangers inherent in using technically complex products to children and those requiring assistance in a way that is easily understandable.

### Electrical voltage



Mounting, installation and servicing work on electrical devices may only be performed by a suitably qualified electrician.

### Servicing

Statutory warranty conditions apply. If the device requires servicing, contact your specialist dealer or electrical installer.

Customer service in the Furtwangen factory  
+49 7723 63-434

### Protect your property!

Lock front doors or apartment doors during the daytime if there is nobody home. Unlocked doors allow thieves/burglars to gain easy access to your property.

The Siedle app can be used from any location as a door release. Keep smartphones on which the Siedle app is activated safe from theft. Protect these devices against unauthorized usage with a code/password. Always use the latest protection mechanisms available for your smartphone.

### Protect your network!

Only use up-to-date components and terminals in the network in line with the latest state of the art. Regularly update the operating systems of all components and terminals. Exchange obsolete components and terminals for up-to-date models. Use professional protective software (antivirus, firewall, ...) in all terminals. Issue secure passwords. Secure your network with the highest security standards available in the network. Protect your network against unauthorized attack from inside and outside.

If you are no longer using an smartphone with the Siedle app installed, either temporarily or over longer periods (repair, sale, exchange), uninstall the app from this device. Never hand over an smartphone with an operable app to a third person!

Delete the affected IP user from the Gateway. This ensures that the affected IP user no longer has access to the door station.

In case of emergency:

- Pull the network cable out of the LAN connection of the Gateway or
- Deactivate the WLAN of the WLAN router
- Block any existing external access to the LAN network.

### Legal notice

Photographs of individuals taken without their knowledge may not be published or stored in publicly accessible video memory facilities. Individuals who have been photographed without their knowledge are entitled to request that pictures be deleted based on the right of persons to their own likeness. Never store pictures of persons you do not know in social networks or send them by email to others/public groups. This will infringe their personal rights.

If stored images are used as part of private / criminal law proceedings or in a police investigation, this requires

prior clarification with a lawyer or the responsible police authority. Systems with video cameras which are operated within the European Union and are aimed at a publicly accessible area or part of one, and film and record this, are subject to the EU General Data Protection Regulation (EU GDPR) as of May 25, 2018. It is the sole responsibility of the operator to operate such systems in accordance with data protection regulations.

### Privacy by Default

In the delivery state, settings relevant to data protection are deactivated „by default“. These include the image memory, direct door call and camera observation.

### Product registration

Siedle software is continuously updated and further developed. To ensure that you make use of all the product benefits and to obtain regular future updates, we recommend that you register your product in the My Siedle Service Portal:

[www.siedle.com/mysiedle](http://www.siedle.com/mysiedle)

### Automatic logout

For security reasons, the Gateway logs out of any session with a logged-in user if no entry has been made in the user interface for 10 minutes. In order to prevent the session time from being extended artificially due to the changes to the time settings, after every change of time setting, an automatic system logout takes place.

## Overview

### System overview

Simplified layout showing arrangement of the Gateway, Siedle app and the installed Siedle intercom in the overall system.


### Possible IP clients\*:

- Siedle app
- Siedle Axiom
- Jung TKM Client (Jung Smart-Control)

\* From software version 2.0.1, the scope of functions is optionally expandable (see page 25).


### Integrable networking components:

- IP cameras (linked via e.g. Siedle Axiom)



## Overview

### Commissioning sequence



### **Bus addresses in the In-Home bus**

As a one-line bus system, the In-Home bus is restricted to a maximum of 31 bus addresses (bus users). A bus video line rectifier is required for the one-line system. If more than 31 bus addresses (bus users) are required, up to 15 bus lines can be coupled with each other in the multiple line bus system. For each bus line, you require a dedicated bus video line rectifier (e.g. 2 bus lines => 62 bus addresses (bus users) => 2 bus video line rectifiers). Irrespective of whether you have a one or multiple line bus system, the Smart Gateway can only reserve the free bus addresses in the bus line in which it is operated. Bus address reservation across different lines is not possible.

Please note that within a bus line, the maximum functional scope is available which has been made available by the relevant programming mode. In cross-line operation between 2 different bus lines, individual functions are not available for technical reasons.

### **Functions applicable across individual lines**

Door calls, selective door dialling and switching and control functions can also be used across individual lines. Internal speech communication and call forwarding between users is only possible within a line.

### **Connection of bus and IP address**

If you are operating the Siedle intercom and the Gateway in the single-line bus system, each component of the intercom is assigned the technically stipulated number of bus addresses (indoor station = 1 bus address and door station = 2 bus addresses). Of a maximum of 31 bus addresses available in the bus line, only the unassigned quantity of bus addresses is then available for additional use in the Gateway. As standard, one bus address is already assigned to the Gateway during programming. Additionally required bus addresses must be manually assigned to the Gateway using the reservation function in the Gateway. Every bus address assigned in the Gateway can be used for connection of an iP user or an IP group, in order to allow these to be directly called individually.

# Overview

## Example – Single line system

Use of one bus line.

### Installation example

The Siedle call station comprises 2 door stations (main and side entrance), 2 indoor stations (storey 0 and 1), 1 Gateway and 1 bus video line rectifier.

Calculation of the additional bus addresses which can be used in the Gateway:

### 1. Bus line

Components	Bus adresses
Door call station Main entrance	2
Door call station Side entrance	2
Internal call station 1	1
Internal call station 2	1
Gateway	1
Sum	7
Max. number of bus addresses per bus line	31
Additionally usable free bus addresses	24

**The result: A maximum of 25 bus addresses can be used in the Smart Gateway for the connection of IP users or IP groups (24 free bus addresses + 1 already assigned bus address of the Smart Gateway).**

## Example – Multiple line system

Use of at least 2 but no more than 15 bus lines.

### Installation example

The Siedle call station comprises 2 door stations (main and side entrance), 2 indoor stations (storey 0 and 1), 1 Gateway and 2 bus video line rectifiers.

The Siedle intercom is supplied via the first bus line and the Gateway via the second bus line. Calculation of the additional bus addresses which can be used in the Gateway:

### 1. Bus line

Components	Bus adresses
Door call station Main entrance	2
Door call station Side entrance	2
Internal call station 1	1
Internal call station 2	1
Sum	6
Max. number of bus addresses per bus line	31
Additionally usable free bus addresses	25

### 2. Bus line

Components	Bus adresses
Gateway	1
Max. number of bus addresses per bus line	31
Additionally usable free bus addresses	30

**The result: A maximum of 31 bus addresses can be used in the Gateway for the connection of IP users or IP groups (30 free bus addresses + 1 already assigned bus address of the Gateway).**

## System limits

### Gateway

Characteristics:	Quantity
Maximum number of assignable bus addresses	31

Maximum amount of IP users per gateway (5 user licenses for a total of 5 IP users are included in the scope of delivery of the gateway). From device version 2.0.1, Siedle Axiom and the JUNG TKM client no longer require user licenses.	10
---	----

Maximum number of IP groups	–
Maximum number of IP users per IP group	6
Cascading: IP group in IP group	0

With an In-Home bus address, you can:

- Selectively call 1 IP user individually through the In-Home bus (e.g. door station)
- or
- Selectively call 1 IP group (with a maximum of 6 IP users) individually through the In-Home bus (e.g. door station).

With 31 In-Home bus addresses, you can:

- Selectively call 31 IP users individually through the In-Home bus (e.g. door station)
- or
- Selectively call 31 IP groups (with a maximum of 6 IP users) individually but in total no more than 10 IP users per Gateway through the In-Home bus (e.g. door station)
- or
- In a mixed configuration with a maximum of 10 IP users, selectively call individual IP users or IP groups (with a maximum of 6 IP users) through the In-Home bus (e.g. door station)

## Preparation

---

### Menu structure User interface

Menu level 1	Menu level 2
<b>Status</b>	Overview IP users Device information
<b>User</b>	User profile Change the password
<b>Basic settings</b>	Date / time Network Video memory / Door call Video Call number prefixes
<b>In-Home bus</b>	Bus addresses Bus users
<b>Network user</b>	Licences IP users IP groups Telephony link
<b>Help</b>	Documentation Commissioning software Support
<b>System</b>	Protocols Safe/Restore Update Reset Restarting
<b>Log out</b>	

---

## Preparation

### Information on programming

In order to use the door intercom system, at least one door call must be programmed in the In-Home bus. Programming is described in detail in the system manual In-Home bus: Video.

In addition to the **basic functions**, you can program additional functions using the **programming software** BPS 650-.... For connecting the PC to the **In-Home bus: Video**, a programming interface PRI 602-.... USB and a ZBVG 650-.... plug-in card are required. The Gateway can be integrated into the In-Home bus in 2 ways:

Programming with the bus programming software (recommended) or manual programming (Teach-In).

### Programming with Bus programming software BPS 650-....

When integrating the Gateway in the In-Home bus using bus programming, a greater functional scope is available at the Gateway (basic functions and supplementary functions).

### Manual programming, also called "Teach-In"

When integrating the Gateway in the In-Home bus using manual programming, only individual functions are available at the Gateway. When carrying out manual programming, you can assign only one bus address to the Smart Gateway, to allow either an IP user or an IP group to be selectively called. If this is not adequate, you must carry out programming using the bus programming software. If you decide in favour of manual programming, the steps with bus programming software are omitted.

### Remarks on the Finder function

In the bus programming software (BPS), the Finder function can be used in order to determine the IP address of the Gateway. Using the Finder function, you can locate all Gateways existing in the network, provided these are located in the same network as the commissioning PC.

Important: A Gateway can only locate the Finder function in the network if the Gateway is in the same subnet of your network (i.e. the first three blocks of the local IP address must be the same – e.g. 192.168.178.xxx).


If the Gateway is not located in the same subnet, you will need to connect your commissioning PC/laptop directly to the Gateway to be able to carry out the configuration.

#### **Important:**

The Gateway must be operated in the local network using a static IP address (not DHCP operation).

### Direct LAN connection

Direct LAN connection between commissioning laptop/PC and Gateway.



#### Conditions:

- Gateway and commissioning laptop/PC are ready for operation.
- The network setting of the Gateway is in the as-delivered status (DHCP client active).
- The DHCP client is enabled on your commissioning Laptop/PC, to be able to request a network address from the DHCP server (router/wireless LAN router/managed switch/server).

#### Procedure:

- 1 Directly connect the commissioning laptop/PC to the Gateway using a network cable.
- 2 Open the web browser and enter the IP address 169.254.1.1 of the Gateway.
- 3 The Login page of the Gateway is opened.

#### Important:


Your browser must accept cookies, otherwise it will not be possible to log in on the login page.

#### Accessibility of the Gateway:

The IP address 169.254.1.1 can also have been used by other device manufacturers. This IP address should therefore only be used with a direct LAN connection.

### Indirect LAN connection with active DHCP server

LAN connection by an existing network (router/wireless LAN router/managed switch/server) with active DHCP server.



#### Conditions:

- Gateway and commissioning laptop/PC are ready for operation.
- The network is active.
- Gateway and PC/Laptop are connected to each other by each network cable on an existing network (router/wireless LAN router/managed switch/server).
- The network setting of the Gateway is in the as-delivered status (DHCP client active).
- The DHCP client is enabled on your commissioning Laptop/PC, to be able to request a network address from the DHCP server (router/wireless LAN router/managed switch/server).

#### Remarks:

- In the delivery status, the Gateway is delivered with an active DHCP client and requests a network address from the DHCP server (router/wireless LAN router/managed

switch/server), whenever a network connection is available.

- Otherwise, find out the IP address of the Gateway either using the Siedle Finder or the bus programming software, via the router/Wi-Fi router/managed switch/server in the area Network/Network settings with the aid of a dedicated network scanner.
- For regular operation, a permanent static IP address is required. This ensures that the Gateway can always be reached under the same IP address.

#### Procedure:

- 1 Connect the Gateway via a network cable to the existing network (router / wireless LAN router / managed switch / server).
- 2 Connect the commissioning laptop/PC via a network cable to the existing network (router / wireless LAN router / managed switch / server).
- 3 Determine the IP address of the Gateway using one of the previously described possibilities. Using the Siedle Finder, the login page of the Gateway can be opened directly via a web browser.
- 4 Open the web browser and enter the determined IP address of the Gateway (e.g. 192.168.178.100).
- 5 The Login page of the Gateway is opened.

#### Important:

Your browser must accept cookies, otherwise it will not be possible to log in on the login page.


#### Accessibility of the Gateway:

The Gateway can be reached under the IP address assigned by the DHCP server (e.g. 192.168.178.100).

## Preparation

### Indirect LAN connection with inactive DHCP server

LAN connection by an existing network (router/wireless LAN router/managed switch/server) with static IP addresses (inactive DHCP server).



#### Procedure:

##### Part A:

- 1 Directly connect the commissioning laptop/PC to the Gateway using a network cable.
- 2 Open the web browser and enter the IP address 169.254.1.1 of the Gateway.
- 3 The Login page of the Gateway is opened.
- 4 If applicable, select a different language.
- 5 Issue a new password which complies with the stipulations.
- 6 Enter the password again.
- 7 Click on Log in.
- 8 The administrator user interface of the Gateway appears.
- 9 Click on Basic settings > Network.
- 10 The network settings are displayed.
- 11 Remove the tick under Obtain IP address automatically by DHCP.
- 12 The network settings are now highlighted in white and can be changed.
- 13 Execute the changes at the network settings.
- 14 Click on the "Apply" button.
- 15 You have changed the network settings, the Gateway will restart.

#### Accessibility of the Gateway:

The Gateway is available under the manually assigned static IP address (e.g. 192.168.178.100).

#### Remark:

For regular operation, a permanent static IP address is required. This ensures that the Gateway can always be reached under the same IP address.

#### Important:

Your browser must accept cookies, otherwise it will not be possible to log in on the login page.

#### Conditions:

- Gateway and commissioning laptop/PC are ready for operation.
- The network is active.
- The IP address range (IP address and subnet mask) of the network (router/wireless LAN router/managed switch/server) must be known. For the Gateway and your commissioning laptop/PC you need a different IP address and subnet mask, to be able to connect both devices with the existing network.
- The network setting of the Gateway is in the as-delivered status (DHCP client active). This is necessary for the initial direct LAN connection.
- The DHCP client is enabled on your commissioning Laptop/PC, to be able to request a network address from the DHCP server (router/wireless LAN router/managed switch/server).

#### Part B:

- 16 Connect the Gateway via a network cable to the existing network (router / wireless LAN router / managed switch / server).
- 17 Connect the commissioning laptop/PC via a network cable to the existing network (router / wireless LAN router / managed switch / server).
- 18 Change the network settings on your commissioning laptop/PC, in accordance with the prescribed network address range (IP address and subnet mask) and save the changes.
- 19 Open the web browser and enter the static IP address of the Gateway (e.g. 192.168.178.100).
- 20 The Login page of the Gateway is opened.

## Commissioning requirements

### Commissioning requirements

Required network properties	Direct LAN connection between the Gateway and commissioning laptop/PC (zero configuration networking: 169.254.1.1) or DHCP-capable network for initial commissioning. For regular operation, a permanent static IP address is required. This ensures that the Gateway can always be reached under the same IP address. Otherwise, find out the IP address of the Gateway either using the Siedle Finder or the bus programming software, via the router/Wi-Fi router/managed switch/server in the area Network/Network settings with the aid of a dedicated network scanner.
Time setting	<ul style="list-style-type: none"><li>• Manual time settings: If there is no facility for automatic time setting, the time must be entered manually.</li><li>• Automatic time setting: You will require an internet connection to a time server in the internet or the address of an internal time server in the LAN in order to adjust this during the configuration. This data must be made available by the customer/system administrator.</li></ul> <p><b>Remark:</b> If the Automatic option has not been selected for Time/date, then the time must be reset after each power failure or reset, as there is no buffer battery. Alternatively, you can operate the Gateway with manual time setting at an uninterruptible power supply.</p>
Sufficient number of user licences	For each IP user (Siedle app, etc.) one user licence is required. There are 5 user licences contained in the scope of supply. Other user licences can be ordered under <a href="http://www.siedle.com/mysiedle">www.siedle.com/mysiedle</a> .
Necessary commissioning software	<ul style="list-style-type: none"><li>• Bus programming software BPS 650-0 – Version: (Latest edition) The bus programming software can be downloaded under <a href="http://www.siedle.com">www.siedle.com</a>.</li><li>• Siedle finder (component of the bus programming software installation)</li><li>• Standard web browser (latest version)</li></ul>
Required documentation	<ul style="list-style-type: none"><li>• Product information Smart Gateway Professional SG 150-0</li><li>• Commissioning instruction</li><li>• System Manual In-Home bus: Video (Latest edition)</li></ul>
Required hardware	<ul style="list-style-type: none"><li>• Commissioning laptop/PC</li><li>• Network cable (RJ45)</li><li>• USB cable (A-&gt;B)</li><li>• Programming interface PRI 602-... USB</li><li>• Bus supply unit accessory ZBVG 650-...</li></ul>
Local access points	<ul style="list-style-type: none"><li>• Local access to the bus video line rectifier and Gateway</li><li>• RJ45 connection to the DHCP-capable LAN/IP network, which is located in the direct vicinity of the Gateway.</li></ul>
Necessary operating software/apps	<ul style="list-style-type: none"><li>• Siedle App for use on smartphones with Android/iOS operating system. Download: Via your terminal with access to the App Store.</li></ul>

# Commissioning requirements

## Fulfilling commissioning requirements

In order to allow the Gateway to be commissioned, the following work must have been completed:

- 1 The door intercom system has been correctly installed/mounted in accordance with the In-Home bus: Video system manual and has been prepared with a programming interface for programming using a PC/laptop (does not apply when programming manually).
- 2 The geographical position of all devices and all required button assignments/functions for the individual devices are documented.
- 3 A commissioning PC/laptop with the latest version of the BPS programming software installed is available for commissioning.
- 4 Network information is available.
- 5 The commissioning technician has knowledge of network technology.
- 6 The commissioning laptop/PC automatically refers to its IP address (DHCP = active).
- 7 The intercom has been completely documented for the In-Home bus and for the IP network.
- 8 The Gateway has been mounted, is ready for operation, connected to the In-Home bus and the commissioning laptop/PC (directly by LAN cable or via a DHCP-capable IP network).
- 9 The commissioning laptop (USB) and the bus video line rectifier (RJ45) have been connected via the programming interface (USB/RJ45).
- 10 The Gateway has been registered with Siedle:  
**[www.siedle.com/mysiedle](http://www.siedle.com/mysiedle)**
- 11 Any existing updates have been saved on the commissioning laptop.
- 12 The bus programming software BPS 650-0 is ready for operation and there is an active connection to the bus video line rectifier (does not apply when programming manually).

## Step-by-step through the commissioning process

The following commissioning steps are described over the following pages:

- 1 Register product
- 2 Define the type of programming (manual programming or programming using the bus programming software).
- 3 Establish the network connection to the Gateway (directly using the LAN cable (Zero Configuration Networking) or indirectly using a DHCP-capable IP network).
- 4 Downloading and installing the bus programming software (Only when programming with bus programming software).
- 5 Program/Configure the In-Home bus with the bus programming software or with manual programming.
- 6 Configure the Gateway
- 7 Install, configure and commission the Siedle app on the terminals.
- 8 Complete function check
- 9 Hand over the complete documentation, system backups and updates to the customer / system administrator.
- 10 Instruct the customer to issue a new and secure password which must not be known to the person carrying out the commissioning.

**Important:** Observe all safety and warning instructions! Also observe all other instructions in this document.

## Register product

Siedle software is continuously updated and further developed. To ensure that you make use of all the product benefits and to obtain regular future updates, we recommend that you register your product in the My Siedle Service Portal:

**[www.siedle.com/mysiedle](http://www.siedle.com/mysiedle)**

For registration, you require the MAC address (hardware address of the Gateway: e.g. 00:10:20:30:a1:b2). The MAC address of the Gateway can be found on the packaging, on the device sticker and in the device information of the browser-based user interface.

## Procedure:

- 1 Register your Gateway on the mysiedle service portal.
- 2 Download existing system updates and save these on your commissioning laptop.

## Downloading and installing the bus programming software

For bus programming of the Gateway, you will need the bus programming software BPS 650. In order to determine the IP address of the Gateway, you will require the Siedle Finder. The Siedle Finder is installed at the same time as the bus programming software. The bus programming software can be downloaded under **[www.siedle.com](http://www.siedle.com)**.

## Procedure:

- 1 Download the bus programming software completely to your commissioning laptop/PC.
- 2 Install the bus programming software completely on your commissioning laptop/PC.

# Commissioning


## Manual programming

### Procedure:


On principle, the In-Home bus can be commissioned and programmed by one person. However, as work has to be executed both at the door loudspeaker and the bus indoor device, we recommend that commissioning be carried out by two people for larger-scale projects.

- Complete the installation
- Check the switch positions at the BNG/BVNG 650-..., in new systems set the switch setting to Norm.
- Activate the programming mode at the bus line rectifier
- Set the door station to the programming mode
- Program the users
- Quit the programming mode


While the bus line rectifier is in the programming mode, several steps can be programmed in sequence. There is no need to quit the programming mode after every operation.




**1** Switch on the programming mode. At the BNG/BVNG 650-..., press the programming mode button briefly. The LED 1 flashes in a 2-second rhythm to indicate that the programming mode is active.




**2** At the door station, hold down the light/programming button for 4 seconds. A protracted acknowledgement tone is then audible which is repeated every 5 seconds as long as the programming mode remains active.



**3** The In-Home LED at the Gateway lights up in green (ready for operation). Press the Prog. button at the Gateway for 3 seconds. The In-Home LED then flashes green.



**4** On the door station, press and hold the desired call button for 4 seconds until a sustained tone can be heard from the door loudspeaker. The call button is now assigned to the bus indoor device.



**5** The call button is now assigned to the Gateway and the basic functions of the In-Home bus are set up. Program additional users using the same procedure or quit the programming mode.

## Programming using the PC and bus programming software (BPS 650-....)

Log into the Gateway using one of the possible connections. On first registering at the Gateway, messages appear about licensing agreements and product registration:

- To be able to use the Gateway, confirm the licensing agreement with **OK**.
- Confirm the registration prompt with **Register now**, if you have not yet registered, and complete the product registration. If registration is not possible at the current time, click on **Later**. Click on **Do not show again** if you have already registered the product.

### Procedure:

**1** Start your web browser, enter the IP address of the Gateway (e.g. 169.254.1.1 or 192.168.178.100) and confirm your entry.

**2** The Login page of the Gateway is opened. The language of the login page depends on the language settings of your commissioning laptop/PC.

**3** If applicable, select a different language.

**4** Enter the relevant password (standard: admin).

**5** Click on Log in.

**6** Confirm the licence conditions with OK.

**7** Confirm the registration prompt if you have already registered, otherwise complete the product registration.

## Performing a system update

Every time before updating the system (upgrade/downgrade), carry out a complete system backup. Ensure that all system backups are safely and permanently stored. During the update process, the power supply must not be interrupted, as otherwise the Gateway will be damaged. During the update, the status LED flashes. Important: After every system update, the option "Persistently store protocols" is deactivated to enable the flash memory for the updating process. This deletes all saved protocols. You should therefore save all protocols to your laptop/PC before every system update.

The system update only affects the Gateway and the connected hardware.

## Update via local update tool

### Procedure:

**1** To access the latest software update, please download the update tool from [www.siedle.de/sg-150](http://www.siedle.de/sg-150)

**2** Save the file with the extension .exe to your hard drive.

**3** Activate the installation process by double-clicking and run the tool.

**4** Confirm any pop-up queries about whether you really want to run the tool.

**5** Select the network connection via which the Gateway can be reached.

**6** On the Gateway's user interface, activate System > Update > Use local update URL

**7** Copy the update URL shown in the local update tool and paste it into the Gateway user interface in the following location: System > Update > Use local update URL

**8** Click the Set update URL button

**9** Click the Start update button

**10** The current system version and the update version are shown.

**11** Select whether a system backup is available or not needed.

**12** Click the Update system button.

During this update process, the Gateway and then the connected hardware will be updated to the latest software version – provided a newer version than the one already installed is available.

### Important

Do not close the tool until all update processes for all devices have completely finished.

## Update via server

If you have a continuous Internet connection, you can also carry out the update via the Siedle update server.

### Procedure:

**1** On the Gateway's user interface activate the option in the following location: System > Update > Use Siedle update server

**2** Click the Check for updates button.

**3** The current system version and the update version are shown.

**4** Select whether a system backup is available or not needed.

**5** Click the Update system button.

During this update process, the Gateway and then the connected hardware will be updated to the latest software version – provided a newer version than the one already installed is available.

## Change user profile / password

### Procedure:

- 1 Click on User > User profile.
- 2 Change/Complete the input fields.
- 3 Confirm your input by clicking on Apply.
- 4 Click on User > Change password.
- 5 Enter the old password (Standard: admin).
- 6 Issue a new password.
- 7 Click on Apply in order to change the password.

## Setting the date and time

For correct local time, and winter/summer time changeover, the relevant time zone must be set. The following values are pre-set in the as-delivered status of the Gateway:

- German timezone (UTC+01:00)
- Automatic summer time change-over deactivated
- Automatic time setting (NTP server) activated

### Procedure:

- 1 Click on Basic settings > Date / time.
- 2 Select your time zone.
- 3 Click on automatic summer time setting if your location changes over between summer and winter time.
- 4 Select how you wish the time setting to take place (automatically/manually). Observe the information on time setting in the commissioning requirements.
- 5 Click on Apply to save your settings/changes.
- 6 You are automatically logged out of the Gateway.

## Check/change the network settings

### Procedure:

- 1 Click on Basic settings > Network.
- 2 Check the network settings for correctness. Change the IP settings if other IP addresses are required or necessary.
- 3 To create a connection with the Internet, the Gateway requires valid network information. If this is entered incorrectly, no connection can be established with the time server in the Internet, or the Apple Push Notification Service for the Siedle app cannot be reached.
- 4 Check the settings you have carried out for correctness. Click on Apply to save any changes you have made.

## Setting video memory/door call

In the menu **Basic settings > Video memory/Door call**, you can carry out settings relating to the video memory and door call. Both setting ranges are visually separated by a frame.

### Procedure:

- 1 Click on Basic settings > Video memory/door call.

## Video memory settings:

- 2 Activate the automatic video memory if you wish an image to be taken of the person calling after every door call.
- 3 Activate the manual video memory if you wish users of the Siedle app to be able to manually take additional images.
- 4 Set the time in seconds after which you wish an image to be automatically taken after a door call (standard setting: 5 seconds).
- 5 Enable automatic deletion of images to automatically delete images that have exceeded the set age (GDPR functionality).
- 6 For automatic deletion of images, set the maximum age of images in days.

## Door call option settings:

- 7 Activate the direct door call if you wish users to be able to call door call stations directly.
- 8 Activate the camera observation if you wish users (except for the Siedle app) to be able to display a live picture from the respective accessible bus/IP camera.

Existing bus cameras can be selected directly.

IP cameras can be additionally integrated into the Siedle IP users (except for the Siedle App). This requires the bus cameras for the camera observation function to have been activated in the Gateway (SG: Basic settings> Video memory/door call >Activate camera observation). With the Siedle IP users, you can select the bus cameras in the operating menu.

- 9 If you install a storey call button in your building, this can be connected directly to the Gateway. However, it is only possible to select a user (except for the Siedle App) for the storey call once you have created an IP user / IP group.

## Video settings

The standard bus camera on the door supports the PAL colour transmission system.

If an NTSC camera is used on the door, then the camera mode must be changed in the Gateway's basic settings.

### Procedure:

- 1 Click on Basic settings > Video.
- 2 Activate NTSC camera mode.
- 3 Click on the "Apply" button.

# Commissioning

## Creating IP users

One licence is required per IP user. There are 5 user licences for IP users contained in the scope of supply. If you require additional user licences, these can be ordered from Siedle at [www.siedle.com/mysiedle](http://www.siedle.com/mysiedle) and imported into the Gateway. For subsequent login of an IP user at the Gateway, the login data issued in the Gateway will be required:

Password

IP address of the Gateway  
(e.g. 192.168.178.100)

### Procedure:

- 1 Click on Network users > IP users.
- 2 Click on Create IP user.
- 3 Select a user type (e.g. Siedle Axiom).
- 4 Complete the information.
- 5 Issue a password according to the system requirements.
- 6 Select the In-Home bus address for the IP user (bus address reference). As standard, the Gateway is assigned one bus address in the In-Home bus.  
(For each IP user / group which you wish to call separately, an additional In-Home bus address must be reserved via the Gateway)
- 7 Click on Save.

## Deleting IP users

All IP users which are registered at the Smart Gateway can only be deleted via the browser-based user interface of the Smart Gateway so that they are no longer displayed as internal users. If a smartphone with registered app is switched off, defective or removed from the reception range of the WiFi router/local area network, or if the app is uninstalled, the created IP user is still displayed as an internal user, even if it can no longer be reached.

In the Status > IP users menu, all the created IP users are listed with the respective login status (idle/offline/busy/unknown).

The user can only be reached in Idle login status.

## Creating IP groups

If several IP users have to be called over the same call button, you can collate these in one IP group. To allow the IP group to be reached via the In-Home bus, a free In-Home bus address must exist.

An IP Group can contain up to 6 IP users.

### Procedure:

- 1 Click on Network user > IP groups
- 2 Click on Create IP group.
- 3 Assign the group name.
- 4 Select the In-Home bus address through which you wish this group to be reachable (bus address reference).
- 5 Click on Add IP user.
- 6 Select the IP users for the IP group by clicking on Add and confirming your selection with Close.
- 7 Save the IP group by clicking on Save.

## Storey call – Defining IP users/ IP group

The call button for the storey call is connected directly at the Gateway (terminal ERT and ETb) and is therefore independent from the rest of the In-Home bus. A door call via the storey call is processed directly in the Gateway.

A storey call can be assigned to one or more IP users (IP group)(except for the Siedle App). The relevant IP users/IP groups must have already been created.

### Procedure:

- 1 Click on Basic settings > Video memory/door call.
- 2 Under users for storey calls, select the relevant IP users / IP group in the drop-down menu.
- 3 Click on Apply to save your settings/changes.

## Registering IP users

To allow the IP users to be connected to the Gateway, the Gateway must be capable of being reached over the network by the relevant IP user.

## Programming in the In-Home bus

### Procedure:

- 1 Connect the PC/laptop to the programming interface using a USB cable.
- 2 Start the programming software BPS 650-...
- 3 Click on **Connect**, to establish an active connection to the In-Home bus.
- 4 Click on **Search** in order to export the system.
- 5 Click on **Find all and add**.
- 6 Confirm the dialogue: **Do you also want to enter the configuration of all In-Home devices?** with **Yes**. The In-Home bus is completely exported. After terminating the process, you will see a device structure at the left-hand side of the BPS software which contains all the devices detected in the In-Home bus.
- 7 Configure all devices and the Gateway.
- 8 Enter easily understandable and meaningful device designations, as these will later appear on all displays.
- 9 Click on the Gateway symbol.
- 10 Select all the devices (e.g. door station) that should be accessible via the Gateway IP side.
- 11 Export the XML configuration file for the Smart Gateway (BPS: SG 150/650 > Create configuration file ...) and save this (e.g. config.xml) on your commissioning laptop.
- 12 Save the BPS system configuration on your PC/laptop.
- 13 Click on the BPS taskbar on **Write**.
- 14 Click in the confirmation dialogue on **Select all**.
- 15 Click on **Write configuration**. The BPS configuration is saved.
- 16 Disconnect from the BPS and end the programming software.

## **Import In-Home bus configuration**

In order to allow the In-Home bus configuration to be transferred to the Gateway, you will require the XML configuration file of the Gateway (e.g. config.xml), which was exported with the bus programming software.

### **Procedure:**

- 1** In the Gateway, click on In-Home bus > Bus users.
- 2** Click on Select file to select the XML configuration file.
- 3** Click on Upload file to import the configuration file into the Gateway.
- 4** Edit the individual bus users by clicking on the pencil symbol and entering the information.
- 5** Click on Apply to save your settings/changes.

## **Siedle app**

The Siedle App is the software-based solution to allow your smartphone to be integrated as a user in the door intercom system. You must install and start the Siedle App on your smartphone and log in using the login data (QR code) assigned in the Gateway.

For successful login, both devices must be connected to the Internet.

### **Always use the latest version of the Siedle app!**

### **Commission the Siedle app**

- 1** Install the Siedle App on your Smartphone. You can obtain the Siedle App from the App Store or Play Store.
- 2** Create a new IP user (Siedle App) in the Smart Gateway.
- 3** A QR code is generated on the Smart Gateway administration interface that you can use to log on to the Siedle app of the mobile device.
- 4** Check whether the Internet connection of the mobile device is active.
- 5** Start the Siedle App on the mobile device.
- 6** Scan the QR code from the Smart Gateway administration interface.
- 7** Alternatively, you can download a PDF document of the QR code, print it out if necessary and scan the code later, keeping the validity period in mind. A new QR code must be generated after the expiration of the period.
- 8** The Siedle App is now linked to the system.
- 9** Carry out a complete function test with the Siedle app.
- 10** The function test must be carried out over the local Wi-Fi connection and over the external mobile phone network.

## **Telephony connection**

### **Siedle Axiom**

External telephone calls (public network telephony) are possible with Siedle Axiom if the device is connected to a telephone system via the Gateway.

To do so, a telephony licence is required. You can find this licence at [www.siedle.com/mysiedle](http://www.siedle.com/mysiedle)

The connection to the TC system must be configured as SIP client in the Gateway.

A Siedle Axiom can be connected via a SIP client.

### **Important**

From firmware version 2.0 optionally three additional function licenses can be purchased for the Smart Gateway SG 150-0: Bus license for BLSHT 250-0 bus software in-house telephone. This license enables the use of the software in-house telephone (BSHT) function in the SG 150.

- Bus licence for external device BLF 250-0. This license enables the use of a VoIP telephone in the SG 150 (optionally with video decoupling).
- Bus licence BLT 250-0 for connection to a telephone system. Buyers of Siedle Axiom receive the equivalent BLT 251-0 licence as a free functional extension for their Smart Gateway or Smart Gateway Professional.

With the two licences BLSHT and BLF, the Smart Gateway SG 150-0 gets the functionality of the Smart Gateway Professional SG 650-0. The limitation to 10 IP users remains with the SG 150-0.

For commissioning of the additional functions, please use the Smart Gateway Professional SG 650-0 commissioning instructions. ([www.siedle.com/sg-650](http://www.siedle.com/sg-650)).

# Commissioning

## Set up SIP client

- 1 Click on Network user > Telephony connection.
- 2 Click on Create connection.
- 3 Select the required mode (SIP client) under Connection type.
- 4 Assign a name, which will later enable unique identification and assignment.
- 5 Enter the IP address of the TC system under Address.
- 6 Enter the port specified by your TC system under Port.
- 7 Select the value supported by the TC system under Audio packet size.
- 8 Enter the name that the Gateway uses to log in to the TC system under TC login name.
- 9 Enter the password that the Gateway uses to log in to the TC system under TC password.
- 10 When logging in with SIP client, enter the realm specified by the TC system, if required.
- 11 When logging in with SIP client, enter the user authentication specified by the TC system, if required.
- 12 Select the supported DTMF mode.
- 13 If required, define a call number prefix.
- 14 Click on the "Apply" button.

## Direct door call per DTMF

A SIP telephone or a TC telephone can actively open a door or activate a door light via a direct door call using DTMF, even if no door call was previously triggered. However, this only applies to TC telephones if they have been created in the Smart Gateway as TC telephones and virtual user. No DTMF signals are evaluated for TC telephones that have not been created.

## Link Siedle Axiom

### Procedure:

- 1 Create the Siedle Axiom in the Gateway as an IP user.
- 2 Under Network users > Telephony connection, open the SIP client that you want to use to link Siedle Axiom.
- 3 Select the relevant Siedle Axiom under call destination.
- 4 Click on the "Apply" button.
- 5 Siedle Axiom is now connected to the TC system.

## Call number prefixes

In this area, the system prefix (default: \*2) for the internal telephony between the IP subscribers is displayed and can be changed here. The prefix for the telephone connection is not displayed until the telephony connection has been set up and a prefix has been assigned.

## Mobile network connection

### Sequence: Install the mobile network connection

1 Check and fulfil the minimum requirements.

2 Update the Gateway


3 Install or update Siedle App on the mobile device.

4 Change the Gateway configuration.

5 Commission the Siedle app.

6 Complete function check.

### Infographic: Connecting a Mobile Terminal to a Smart Gateway



# Mobile network connection

## Mobile network connection

From Release V. 2.0, a mobile network connection via 3G/4G/5G can be configured according to the following description.

## Important

If you have already operated a mobile network connection with an earlier device version, you should remove all port forwards that have been set up for this in routers or other network components! No port forwarding is required for the mobile network connection from device version 2.0.1!

## Sequence:

- 1 Check and fulfil the minimum requirements.
- 2 Update the Gateway
- 3 Install or update Siedle App on the mobile device.
- 4 Change the Gateway configuration.
- 5 Commission the Siedle app.
- 6 Complete function check.

## Minimum requirements for stationary internet connection

- Internet protocol: IPv4 connection with static or dynamically changing public IP address.
- Download: Constant at least 512 kBit/s (exclusively for this application).
- Upload: The frame rate (number of frames per second) of the transmitted video stream from the Smart Gateway to the Siedle Server depends on the data transmission rate that is available for this connection at the time of the door call. The Smart Gateway dynamically adapts the frame rate to the available bandwidth:
  - Minimum bandwidth: 2 MBit/s (approx. 5 frames/second)
  - Recommended bandwidth: 4 MBit/s (approx. 10 frames/second)
- Continuous connection to the Internet.
- SIP-VoIP: Transmission of SIP-VoIP data packages not originating from the provider (internet telephony) enabled.

## Note:

Router-specific safety settings may not impair or prevent the internal and external accessibility of the Gateway.


## Minimum requirements for mobile terminals

- Internet protocol: IPv4 connection with static or dynamically changing public IP address
- Download: The frame rate (number of frames per second) of the transmitted video stream from the Siedle Server to the Siedle App depends on the data transmission rate that is available for the mobile network connection at the time of the door call:
  - Bandwidth 2 MBit/s: approx. 5 frames/second are shown
  - Bandwidth 4 MBit/s: approx. 10 frames/second are shown
- Upload: Constant 512 kBit/s (exclusively for this application)
- Stable WLAN or mobile phone connection (3G/4G/5G)
- SIP-VoIP: Transmission of SIP-VoIP data packages not originating from the provider (internet telephony) enabled
- Optionally: VoLTE services (Voice over LTE). When using a mobile phone network over LTE, an actively held door call will not be disconnected by an incoming mobile phone call. The door call can be continued as soon as the incoming call has been rejected or terminated.
- Operating system up to date.
- Fully installed Siedle App of the current version.

## Commission the Siedle app

- 1 Create a new IP user (Siedle App) in the Smart Gateway.
- 2 A QR code is generated on the Smart Gateway administration interface that you can use to log on to the Siedle app of the mobile device.
- 3 Check whether the Internet connection of the mobile device is active.
- 4 Start the Siedle App on the mobile device.
- 5 Scan the QR code from the Smart Gateway administration interface.
- 6 Alternatively, you can download a PDF document of the QR code, print it out if necessary and scan the code later, keeping the validity period in mind. A new QR code must be generated after the expiration of the period.
- 7 The Siedle App is now linked to the system.
- 8 Carry out a complete function test with the Siedle app.
- 9 The function test must be carried out over the local Wi-Fi connection and over the external mobile phone network.

## Infographic: Mobile phone network requirements



## Reset or check the settings

### Resetting the system

To allow the as-delivered status to be restored at the Gateway, the Gateway must be reset. All settings / configurations are reset to the as-delivered status in this process.

A confirmation prompt appears which you have to confirm. If you reset the system to the as-delivered status, any settings, logs, operating data (e.g. image) which are not backed up will be completely lost.

**Important: After every system update, the option "Persistently store protocols" is deactivated to enable the flash memory for the updating process. This deletes all saved protocols. You should therefore save all protocols to your laptop/PC before every system update.**

#### Procedure:

**1** Click on the menu System > Reset.  
**2** Click on Restore as-delivered status in order to reset the Gateway.  
**3** In response to the confirmation prompt, click on Yes if you wish to reset the Gateway.

### Restarting the Gateway

If the IP settings have been changed in the IP network with DHCP operation, the Smart Gateway has to be restarted. A restart corresponds to switching the power supply to the Smart Gateway off and on again. After a restart, the Smart Gateway again requests an IP address in DHCP operation. It is possible that the Smart Gateway can be reached under a different IP address than before the restart.

#### Procedure:

**1** Press the Reset button at the Gateway for 1 second.  
**2** The Gateway is restarted and obtains the IP settings.

#### Note:

A restart can also be initiated via the administration interface (menu: System > Restart).

### IP address and password reset

You can reset the settings for the IP address and the password for login at the Gateway without the need to access the user interface. This may be necessary if the customer/system administrator no longer knows the password or due to IP address changes in the IP network, the Gateway can no longer be addressed with a permanently assigned IP address in the changed network.

#### Procedure:

**1** Press the programming button at the Gateway for at least 10 seconds and hold it down until the status LED starts flashing red.  
**2** The status LED at the Gateway flashes red for a period of 3 seconds.  
**3** Release the programming button within the 3-second flashing phase and press it again within the 3-second flashing phase.  
**4** The settings for the IP address and the password are reset to the as-delivered status.  
**5** Determine the IP address of the Smart Gateway using the Siedle finder. Alternatively, the IP address of the Smart Gateway can be determined through the DHCP server or using your own network scanner.  
**6** Log in to the Gateway.  
**7** Issue a new password which complies with the stipulations.

### DHCP server – Changes

If the DHCP server (Router/Wi-Fi router/managed switch/server) is exchanged in your network or its configuration is altered, the Gateway can be assigned a new IP address and would then no longer be capable of being accessed. In such a case, registration of the Siedle app for Gateway has to be carried out using the new IP address of the Gateway.

The new IP address of the Gateway can be determined using the finder function.

### Carry out a function check

#### Procedure:

**1** Carry out a complete function test with all bus and IP users and all the functions you have set up.  
**2** Back up the In-Home bus configuration and the configuration of the Gateway on your commissioning laptop.  
**3** Hand over all the files (system backup, update, licence and configuration files from the BPS for the In-Home bus and the Gateway), the system documentation and the changed access data to the customer/system administrator.  
**4** After transferring, delete all commissioning files from your commissioning laptop.  
**5** Inform your customer/the system administrator that after completion of the commissioning process, a new access password must be issued without fail for the Gateway which may be unknown to you.

## Optional commissioning steps

### Reserving bus addresses

As standard, the Gateway is assigned one bus address in the In-Home bus. An IP user or an IP group made up of at least 2 IP users could then be called using this bus address.

In order to allow additional IP users/ IP groups (e.g. Siedle app) to be called separately via the In-Home bus, the Gateway requires additional In-Home bus addresses.

For each IP user / group which you wish to call separately, an additional In-Home bus address must be reserved via the Gateway.

#### Remark:

Only freely available In-Home bus addresses can be reserved. If more In-Home bus addresses are requested than are available, the maximum quantity of free In-Home bus addresses in the relevant bus line are reserved in the Gateway.

#### Example:

At the Gateway, you are operating one Siedle app for Gateway and one bus software in-house telephone. Both IP users should be capable of being called separately.

For the Gateway, only one In-Home bus address would be assigned as standard. This bus address could therefore only be assigned to an IP user or to a group with several or all IP users. All other network users would not be able to be called via the In-Home bus.

#### Solution:

You will require an additional In-Home bus address in order to be able to call both IP users separately.

#### Procedure:

- 1 Log in to the Gateway.
- 2 Click on In-Home bus > bus addresses.
- 3 Click on Reserve bus address(es).
- 4 Enter the number of bus addresses you wish to reserve.

**5** Click on Apply in order to start the reservation process.

**6** In the header of the Gateway, the following message appears: Searching for reservable bus addresses in the In-Home bus. The search can take several minutes.

**7** During the active search, the In-Home LED flashes at the Gateway and the LED1 flashes on the BNG/ BVNG.

**8** If the required number of In-Home bus addresses has been reserved, the following message appears: Reservation successfully completed.

**9** Start the programming mode at the bus video line rectifier, and end it after 2 seconds at the earliest.

**10** The reserved In-Home bus address(es) has/have been assigned to the Gateway and can be used for programming/configuring the In-Home bus.

**11** Repeat the steps for programming with PC and Bus programming software BPS 650-...

### Licenses

#### User licences

There are 5 user licences for IP users contained in the scope of supply. For each IP user you wish to be able to call separately, you will require a user licence.

If you require additional licences, these can be ordered from Siedle ([www.siedle.de/mysiedle](http://www.siedle.de/mysiedle)) and imported into the Gateway. Accessing is only possible subject to prior product registration.

#### Remark:

To import the user licences, a licence file is required with the file suffix .xml.

#### Procedure:

- 1 Click on Network users > licences.
- 2 Click on Select file ...
- 3 Select the licence file supplied by Siedle and confirm your selection with Open.
- 4 Click on Upload file to import the licence information.

**5** After successful import of the licence file, a confirmation appears and the number of licences has changed.

**6** Hand over the licence file to your customer/system administrator.

### Function licences

From firmware version 2.0 optionally three additional function licenses can be purchased for the Smart Gateway SG 150-0: Bus license for BLSHT 250-0 bus software in-house telephone. This license enables the use of the software in-house telephone (BSHT) function in the SG 150.

- Bus licence for external device BLF 250-0. This license enables the use of a VoIP telephone in the SG 150 (optionally with video decoupling).
- Bus licence BLT 250-0 for connection to a telephone system. Buyers of Siedle Axiom receive the equivalent BLT 251-0 licence as a free functional extension for their Smart Gateway or Smart Gateway Professional.

With the two licences BLSHT and BLF, the Smart Gateway SG 150-0 gets the functionality of the Smart Gateway Professional SG 650-0. The limitation to 10 IP users remains with the SG 150-0.

For commissioning of the additional functions, please use the Smart Gateway Professional SG 650-0 commissioning instructions. ([www.siedle.com/sg-650](http://www.siedle.com/sg-650)).

## Optional commissioning steps

### Logging


The Gateway benefits from extensive system logging. The logs are located in the submenu Logs (System > Logs).

The scope of logging can be altered by changing the log level.

In the as-delivered status of the Gateway, the log level is on Error. Changes at the log level are saved by the system.

The protocols can be stored optionally as "persistent", to ensure that they can be evaluated even after a reset to the as-delivered status (e.g. in case of a fault).

The following logging levels exist in the drop-down menu:

Log level	Logging intensity
Emergency	
Error	
Warning	
Info	
Debug	
Trace	

In the log level **Emergency**, only serious system-related faults are logged. In the log level **Trace**, all loggable events are logged and saved in different log files. The log files can be opened, downloaded and deleted under System > Logs. Please note that the log level **Trace** requires a higher proportion of the system resources, is only designed for troubleshooting and not for continuous operation.

### Remark:

The logs are not included in the system backup. If you wish to reset the Gateway to the as-delivered status, if required save the protocol files on your laptop/PC or activate the option "Save protocols persistently" in the "System > Protocols" menu.

**Important: After every system update, the option "Persistently store protocols" is deactivated to enable the flash memory for the updating process. This deletes all saved protocols. You should therefore save all protocols to your laptop/PC before every system update.**

### Procedure:

- 1 Click on System > Protocols.
- 2 Click the download icon to save the required log file.

### Backing up/Restoring the system

In the Gateway, you can back up and restore the configuration data, the operating data or also both together.

After completion of the successful function test, back up the whole system and hand the files to the customer/system administrator.

During a system restore process, the power supply to the Gateway must not be interrupted, as otherwise the Gateway will be damaged.

### Configuration data + operating data:

All settings and operating data are backed up and restored in one file (file format: BAK).

### Configuration data:

All settings are backed up and restored in one file (file format: BAK).

### Operational data:

All operating data is backed up and restored in one file (file format: ZIP). The operating data contains the content of the video memory and can be unpacked, opened and viewed for evaluation/analysis by the customer/system administrator.

### Procedure: Backing up the system

- 1 Click on System > Backup / Restore.
- 2 In the Backup area, select which data (configuration data/operating data) you wish to back up.
- 3 Click on Back up system and save the back-up file on your commissioning laptop.
- 4 Hand over the backup file to your customer/system administrator.

### Procedure:

#### Restoring the system

- 1 Click on System > Backup / Restore.
- 2 In the Restore area, click on Select file ...
- 3 Select the restore file on your PC/laptop and confirm your selection with Open. To restore the configuration of the Gateways, a file is required in BAK file format (e. g. Backup.bak).
- 4 Click on the Restore system button in order to start the system restore process.

# Index

Accessibility of the Gateway	11	Integrable networking components	5	Siedle Axiom	19, 20
App	19	IP address and password reset	24	Single line system	7, 8
As-delivered status	24	IP users	5, 8, 18, 25	Step-by-step through the commissioning process	14
Automatic logout	4	Jung TKM Client	5	Storey call – Defining IP users/IP group	18
Backing up/ Restoring the system	26	Legal notice	4	System limits	8
Basic functions	10, 15	Licences	25	System overview	5
Bus address reference	18	Local access points	13	Time setting	13
Bus addresses in the In-Home bus	25	Log level	26	Trace	26
Bus line	7, 8	Logging	26	Use of at least 2 but no more than 15 bus lines	8
Call number prefixes	20	Login on the Gateway	12, 16, 18, 22	Use of one bus line	8
Carry out a function check	24	Manual programming	10, 15	User licences	25
Carry out the update	16	Menu structure User interface	9	Video memory settings	17
Change user profile / password	17	Mobile network connection	21	Warning	26
Check/change the network settings	17	Multiple line system	8		
Commissioning requirements	13, 14	Network characteristics	13		
Commissioning software	13	Observe the safety instructions!	4		
Configuration data	26	Operating software/apps	13		
Creating IP groups	18	Operational data	26		
Date / time	17	Optional commissioning steps	25		
Debug	26	Performing a system update	16		
DHCP server – Changes	24	Possible IP clients	5		
Direct LAN connection	11	Preparation	9		
Door call option settings	17	Programming using the PC and bus programming software (BPS 650-...)	16		
Downloading and installing the bus programming software	14	Protect your network!	4		
Electrical voltage	4	Protect your property!	4		
Emergency	26	Register product	14		
Error	26	Required documentation	13		
Function licences	25	Required hardware	13		
Functions applicable across individual lines	7	Reserving bus addresses	25		
Import bus configuration	19	Reset button	24		
Import licences	25	Resetting the system	24		
Indirect LAN connection with active DHCP server	11	Restarting	24		
Indirect LAN connection with inactive DHCP server	12	Restarting the Gateway	24		
Info	26	Servicing	4		
		Setting the door call	17		
		Setting video memory/video call	17		
		Siedle app	19		

# SSS SIEDLE

S. Siedle & Söhne  
Telefon- und Telegrafenwerke OHG  
Postfach 1155  
78113 Furtwangen  
Bregstraße 1  
78120 Furtwangen

Telefon +49 7723 63-0  
Telefax +49 7723 63-300  
[www.siedle.de](http://www.siedle.de)  
[info@siedle.de](mailto:info@siedle.de)

© 2017/04.21  
Printed in Germany  
Best. Nr. 210009601-00 EN