












































































Available Iconsets on TouchIT-C3 : 01.06.2011

	Iconset Name	Status ON	Status OFF	Button ON	Button OFF	Button DOWN	Button UP
1	1staid						
2	acc_cancel						
3	bell						
4	bass						
5	dnd						
6	door						
7	err_pause						
8	shutter						
9	green_red						
10	guest						
11	in_out						
12	light						
13	lightbulb						
14	mur						
15	sound						
16	socket						
17	treble						
18	volume						
19	window	