



**CJC** SYSTEMS

DESIGN SWITCHES **KNX COLLECTIONS**



## INDEX


Anna CARRE	04
Anna BANDE	05
Zita CARRE	06
Zita BANDE	07
Mona CARRE	08
Mona BANDE	09
Lara CARRE	10
Lara BANDE	11
Lola CARRE	12
Lola BANDE	14

The wide selection of push buttons from CJC Systems includes 5 different ranges: LOLA, MONA, ZITA, LARA and ANNA. Inside of each range we can find 2 versions: CARRE and BLANDE, which differ from each other in the width of the push buttons and they are all available in different finishes: aluminum natural anodised, black bronze anodised, brass anodised, brushed stainless steel, brown bronze painted, gilded 24 carat, glossy chromium, white painted, black painted, customized painted RAL colour. Besides from the possibility of choosing different number of keys these pushbuttons can include (on request) status LEDs as well as humidity and temperature sensor.

## available **COLORS**




CJC .... A  
Alu Natural  
Anodised




CJC .... X  
Brushed  
Stainless Steel



CJC .... RAL9003  
White Painted  
RAL900




CJC .... B  
Black Bronze  
Anodised



CJC .... BR  
Brown Bronze  
Painted



CJC .... RAL9011  
Black Painted  
RAL9011



CJC .... G  
Grey Anodised




CJC .... V  
Gilded 24 Carat



CJC .... RAL ....  
Customized  
Painted  
RAL Colour



CJC .... M  
Brass Anodised



CJC .... C  
Glossy  
Chromium




Anna **CARRE**

DESIGN SWITCHES KNX COLLECTIONS



**1 lever**  
1 central red LED  
2 yellow control LEDs  
CJC1021A - CJC1021**THA**



**1 lever**  
no LED  
CJC1601A - CJC1601**THA**



**2 levers**  
1 central red LED  
4 yellow control LEDs  
CJC1022A - CJC1022**THA**



**2 levers**  
no LED  
CJC1602A - CJC1602**THA**




**3 levers**  
1 central red LED  
6 yellow control LEDs  
CJC1023A - CJC1023**THA**



**3 levers**  
no LED  
CJC1603A - CJC1603**THA**




**4 levers**  
1 central red LED  
8 yellow control LEDs  
CJC1024A - CJC1024**THA**



**4 levers**  
no LED  
CJC1604A - CJC1604**THA**

TH= with temperature & humidity sensor




Anna **BANDE**

DESIGN SWITCHES KNX COLLECTIONS



**1 lever**  
1 central red LED  
2 yellow control LEDs  
CJC1321A - CJC1321**THA**



**1 lever**  
no LED  
CJC3621A - CJC3621**THA**



**2 levers**  
1 central red LED  
4 yellow control LEDs  
CJC1322A - CJC1322**THA**



**2 levers**  
no LED  
CJC3622A - CJC3622**THA**



**3 levers**  
1 central red LED  
6 yellow control LEDs  
CJC1323A - CJC1323**THA**



**3 levers**  
no LED  
CJC3623A - CJC3623**THA**



**4 levers**  
1 central red LED  
8 yellow control LEDs  
CJC1324A - CJC1324**THA**



**4 levers**  
no LED  
CJC3624A - CJC3624**THA**



Zita **CARRE**

DESIGN SWITCHES KNX COLLECTIONS



**1** push-button  
with white LED  
1 central red LED  
CJC2761A



**2** push-buttons  
with white LEDs  
1 central red LED  
CJC2762A - CJC2762THA



**3** push-buttons  
with white LEDs  
1 central red LED  
CJC2763A



**4** push-buttons  
with white LEDs  
1 central red LED  
CJC2765A - CJC2765THA

TH= with temperature & humidity sensor

## Zita BANDE

DESIGN SWITCHES KNX COLLECTIONS



**1** push-button  
with white LED  
1 central red LED  
CJC2861A



**2** push-buttons  
with white LEDs  
1 central red LED  
CJC2862A - CJC2862THA



**3** push-buttons  
with white LEDs  
1 central red LED  
CJC2863A



**4** push-buttons  
with white LEDs  
1 central red LED  
CJC2865A - CJC2865THA



Mona **CARRE**

DESIGN SWITCHES KNX COLLECTIONS




**1** push-button  
push-button  
with white LED  
CJC2781A



**1** push-button  
no LED  
CJC2791A



**2** push-buttons  
with white LEDS  
1 central red LED  
CJC2782A - CJC2782THA



**2** push-buttons  
no LED  
CJC2792A - CJC2792THA



**3** push-buttons  
with white LEDS  
1 central red LED  
CJC2783A



**3** push-buttons  
no LED  
CJC2793A



**4** push-buttons  
with white LEDS  
1 central red LED  
CJC2785A - CJC2785THA



**4** push-buttons  
no LED  
CJC2795A - CJC2795THA



**4 + 4** push-buttons  
with white LEDS  
2 central red LEDS  
CJC2885A



**4 + 4** push-buttons  
no LED  
CJC2895A

TH= with temperature & humidity sensor





Mona **BANDE**

DESIGN SWITCHES KNX COLLECTIONS



**1** push-button  
with white LED  
1 central red LED  
CJC2981A



**1** push-button  
no LED  
CJC2991A



**2** push-buttons  
with white LED  
1 central red LED  
CJC2982A - CJC2982**THA**



**2** push-buttons  
no LED  
CJC2992A - CJC2992**THA**



**3** push-buttons  
with white LEDs  
1 central red LED  
CJC2983A



**3** push-buttons  
no LED  
CJC2993A




**4** push-buttons  
with white LEDs  
1 central red LED  
CJC2985A - CJC2985**THA**



**4** push-buttons  
no LED  
CJC2995A - CJC2995**THA**

TH= with temperature & humidity sensor



Lara **CARRE**


DESIGN SWITCHES KNX COLLECTIONS




**1** push-button  
with white LEDS  
1 central red LED  
CJC2741A - CJC2741**THA**




**2/4** push-buttons  
with white LEDS  
1 central red LED  
CJC2742A - CJC2742**THA**




**2/4 + 1** push-buttons  
with white LEDS  
2 central red LEDS  
CJC2841A



**2/4 + 2/4** push-buttons  
with white LEDS  
2 central red LEDS  
CJC2842A



**1** push-buttons  
with white LEDS  
1 central red LED  
1 x socket outlet/2 modules  
CJC2941A



**2/4** push-buttons  
with white LEDS  
1 central red LED  
1 x socket outlet/2 modules  
CJC2942A

TH= with temperature & humidity sensor



**futurasmus**  
KNX GROUP

Lara **BANDE**

DESIGN SWITCHES KNX COLLECTIONS



**1** push-button  
with white LEDS  
1 central red LED  
CJC3041A - CJC3041**THA**




**2/4** push-buttonS  
push-buttons  
1 central red LED  
CJC3042A - CJC3042**THA**

TH= with temperature & humidity sensor




Lola **CARRE**


DESIGN SWITCHES KNX COLLECTIONS



**1** push-button  
1 white LED  
CJC2731A - CJC2731**THA**



**1** push-button  
no LED  
CJC3031A - CJC3031**THA**




**2** push-buttons  
2 white LEDs  
CJC2732A - CJC2732**THA**




**2** push-buttons  
no LED  
CJC3032A - CJC3032**THA**




**3** push-buttons  
3 white LEDs  
CJC2733A - CJC2733**THA**



**3** push-buttons  
no LED  
CJC3033A - CJC3033**THA**




**4** push-buttons  
4 white LEDs  
CJC2734A - CJC2734**THA**




**4** push-buttons  
no LED  
CJC3034A - CJC3034**THA**


TH= with temperature & humidity sensor



**5** push-buttons  
5 white LEDs  
CJC2735A




**5** push-buttons  
no LED  
CJC3035A




**6** push-buttons  
6 white LEDs  
CJC2736A




**6** push-buttons  
no LED  
CJC3036A




**7** push-buttons  
7 white LEDs  
CJC2737A




**7** push-buttons  
no LED  
CJC3037A




**8** push-buttons  
8 white LEDs  
CJC2738A




**8** push-buttons  
no LED  
CJC3038A



**5** push-buttons  
5 white LEDs  
CJC2835A




**5** push-buttons  
no LED  
CJC3135A




**6** push-buttons  
6 white LEDs  
CJC2836A




**6** push-buttons  
no LED  
CJC3136A




**7** push-buttons  
7 white LEDs  
CJC2837A



**7** push-buttons  
no LED  
CJC3137A




**8** push-buttons  
8 white LEDs  
CJC2838A




**8** push-buttons  
no LED  
CJC3138A






Lola **BANDE**


DESIGN SWITCHES KNX COLLECTIONS




**1** push-button  
1 white LED  
CJC2931A - CJC2931**THA**



**1** push-button  
no LED  
CJC3231A - CJC3231**THA**



**2** push-buttons  
2 white LEDs  
CJC2932A - CJC2932**THA**



**2** push-buttons  
no LED  
CJC3232A - CJC3232**THA**



**3** push-buttons  
3 white LEDs  
CJC2933A - CJC2933**THA**



**3** push-buttons  
no LED  
CJC3233A - CJC3233**THA**



**4** push-buttons  
4 white LEDs  
CJC2934A - CJC2934**THA**



**4** push-buttons  
no LED  
CJC3234A - CJC3234**THA**