


Radio Control System Solexa II – Menu overview


BASE SETTINGS

 In order to open the base settings, press the settings symbol on the home screen for a longer time (approx. 3 seconds) until the high beep „long key stroke“ sounds.



GENERAL AUTOMATIC SETTINGS


 To access the automatic settings, press the settings symbol on the home screen briefly.



Radio Control System Solexa II – Menu overview


SHADING AUTOMATIC FUNCTIONS (shutter, awning, blinds)

 To access the automatic settings, press the settings symbol on the home screen briefly.



VENTILATION AUTOMATIC FUNCTIONS (WINDOW)


 To access the automatic settings, press the settings symbol on the home screen briefly.



Radio Control System Solexa II – Menu overview


LIGHT AUTOMATIC FUNCTIONS

 To access the automatic settings, press the settings symbol on the home screen briefly.



HEATING AUTOMATIC FUNCTIONS

 To access the automatic settings, press the settings symbol on the home screen briefly.



DEFROST AUTOMATIC FUNCTIONS (roof gutter heating)

