

This document describes how to link the Intesis AC Cloud Control device (hereafter referred to as "AC Cloud Control") to the Wi-Fi network without being logged in, using the Automatic mode. For other configuration modes, please refer to the [Device Configuration](#) manual.

This configuration guide applies to AC Cloud Control Brand Specific RC devices with order codes different to INWFIXXX001R1XX. For the INWFIXXX001R1XX code, please refer to the [Quick Wi-Fi Configuration with Bluetooth](#) guide.

Note:

- The AC Cloud Control generates its own network named DEVICE_XXXXXX or INTESISHOME_XXXXXX, being XXXXXX the last 6 digits of the AC Cloud Control MAC address.
- To link the AC Cloud Control to the Wi-Fi, configure the Access point in the 2.4GHz band and the 802.11 b/g or /n mode.
- If the generated network is INTESISHOME_XXXXXX, your Access point must allow b mode.
- Memorize the name and password of the Wi-Fi network to which you want to link the AC Cloud Control.

What is needed:



Before starting the linking process with the App:

1. Install the AC Cloud Control following the corresponding [Installation manual](#).
2. Keep your Smart device close to both the Access point and the AC Cloud Control.
3. Connect your Smart device to the AC Cloud Control network.

Once you completed the previous steps, open the AC Cloud Control App and proceed as follows:

The warning message (step 7), only appears if the AC Cloud Control network is named INTESISHOME_XXXXXX

