

Product data sheet

Rocker with lens and arrow symbols for KNX push-button 1-gang



Reference number

AS 101 KO5P WW

1-gang rocker with lens and arrow symbols

for JUNG HOME push-button 1-gang, battery-powered, ref.-no.: BT A 1001
for KNX push-button 1-gang ref.-no.: A 1071 1ST, A 1091 1ST

Duroplastic (scratch-proof) glossy

Colour:
white

Material:
duroplastic