

Product data sheet

Rocker with lens and arrow symbols for KNX push-button 1-gang Rocker with lens and arrow symbols for KNX push-button 2-gang



Reference number
A 101 KO5P BF WWM
1-gang rocker with lens and arrow symbols 2-gang rocker with lens and arrow symbols
for JUNG HOME push-button 1-gang, battery-powered, ref.-no.: BT A 1001 for KNX push-button 1-gang ref.-no.: A 1071 1ST, A 1091 1ST for JUNG HOME push-button 2-gang, battery-powered, ref.-no.: BT A 1002 for KNX push-button 2-gang ref.-no.: A 1072 1ST, A 1092 1ST
matt lacquered
Colour: matt snow white
Material: thermoplastic lacquered