Interface KNX V2

UNIDAD CENTRAL	GENERAL STANDBY	WRITE
	DATE	WRITE
	TIME	WRITE
	FM MEMORY +/-	WRITE
	FM FREQUENCY	WRITE/READ
	CD/DVD AUDIO PLAYER SONG +/-	WRITE
	IPOD SONG +/-	WRITE
ZONAS 1-24	STANDBY ON/OFF	WRITE
	CHANNEL +/-	WRITE
	CHANNEL	WRITE/READ
	VOLUME +/-	WRITE
	VOLUME	WRITE/READ
	FM MEMORY +/-	WRITE
	FM FREQUENCY	WRITE/READ

UNIDAD CENTRAL	GENERAL STANDBY	WRITE
	DATE	WRITE
	TIME	WRITE
	FM AUTO-SCAN	WRITE
	FM MEMORY +/-	WRITE
	FM FREQUENCY	WRITE/READ
	FM RDS INFORMATION	READ
	DISK PLAY/PAUSE	WRITE
	DISK SONG +/-	WRITE
	DISK SONG	READ
	IPOD PLAY/PAUSE	WRITE
	IPOD SONG +/-	WRITE
	IPOD SONG	READ
	IPOD ARTIST	READ
	IPOD ALBUM	READ
	IPOD PLAYLIST	READ

ZONAS 1-13	STANDBY ON/OFF	WRITE/READ
	CHANNEL	WRITE/READ
	VOLUME +/-	WRITE
	VOLUME	WRITE/READ
	BASS +/-	WRITE
	BASS	READ
	TREBLE +/-	WRITE
	TREBLE	READ
	LOUDNESS ON/OFF	WRITE
	LOUDNESS	READ
	FM AUTO-SCAN	WRITE
	FM MEMORY +/-	WRITE
	FM FREQUENCY	WRITE/READ
	FM RDS INFORMATION	READ

Nuevas características